



# User Manual

## Communication Function Ver\_6

( Rev.04)



## **- Table of Contents -**


<b>1 . Communication Protocols.....</b>	<b>4</b>
<b>1 - 1 . Communication Functions.....</b>	<b>4</b>
1 - 1 - 1 . Communication Specifications.....	4
1 - 1 - 2 . RS-485 Communication Protocol(Ver6) .....	4
1 - 1 - 3 . CRC Calculation Example .....	5
1 - 1 - 4 . Response Frame Structure and Communication Error(Ver6) .....	7
<b>1 - 2 . Structure of Frame .....</b>	<b>9</b>
1 - 2 - 1 . Frame type and Data Configuration .....	9
1 - 2 - 2 . Parameter Lists.....	22
1 - 2 - 3 . Bit setting of the control output pin .....	23
1 - 2 - 4 . Bit setting of the control input pin .....	24
1 - 2 - 5 . Bit setting of Status Flag.....	25
<b>1 - 3 . Program Type.....</b>	<b>28</b>
<b>2 . Library for PC Program(Ver6).....</b>	<b>29</b>
<b>2 - 1 . Library Configuration.....</b>	<b>29</b>
<b>2 - 2 . Communication Status Window .....</b>	<b>30</b>
<b>2 - 3 . Commuication Link Function .....</b>	<b>35</b>
<b>2 - 4 . Parameter Control Function.....</b>	<b>44</b>
<b>2 - 5 . Servo Control Function.....</b>	<b>50</b>
<b>2 - 6 . Control I/O Function .....</b>	<b>54</b>
<b>2 - 7 . Position Control Function .....</b>	<b>68</b>
<b>2 - 8 . Status Control Function.....</b>	<b>79</b>
<b>2 - 9 . Running Control Function .....</b>	<b>86</b>

2 - 10 . Other Control Function.....	128
3 . Protocol for PLC Program.....	132

# 1 . Communication Protocols

## 1 – 1. Communication Functions

Ezi-MOTIONLINK-Plus-R can control up to 16 axes by multidrop link at RS-485(two-wire) using Daisy-Chain.

 <b>Caution</b>	<b>Pay attention that when Windows goes into standby or power-save mode, serial communication is basically disconnected. When the system is recovered from standby mode, it should be connected again with serial communication. This is also applicable to the library provided.</b>
--	---

### 1 – 1 – 1. Communication Specifications


Specification	RS-485
Communication Type	Asynchronous
	Half-duplex
Baud Rate [bps]	19200, 38400, 57600, 115200, 230400,460800,921600
Data Type	8bit Binary ASCII Code, HEX
Parity	No
Stop Bit	1bit
CRC Check	Yes(CRC-16)
Max Cabling Length (Converter ↔ End of Ezi-MOTIONLINK-Plus-R)	Within 30 [m]
Min Cable length between Ezi-MOTIONLINK-Plus-R	More than 60 [cm]
Number of Connected Axes	16 axes (No. 0~F)

### 1 – 1 – 2. RS-485 Communication Protocol(Ver6)


Thers are 2 kinds of GUI version. This manual support for 'Version 6' level.

Type	Firmware version	compatability	User Program(GUI) version
1	Level 6 (V06.0x.0xx.xx)	<->	Level 6 (6.xx.x.xxx)
2	Level 8 (V08.xx.0xx.xx)	<->	Level 8 (8.xx.x.xxx)

After connect the User Program(GUI),  
Version number can be check in  
'About Plus-R GUI...'menu in 'Help' menu.



## 1) Overview of communication FRAME



## 2) Basic structure of Frame

Header	Frame Data	Tail
0xAA 0xCC	4~252 bytes	0xAA 0xEE

- ① 0xAA : Delimited byte
- ② 0xAA 0xCC : Displays that the Frame locates in header.
- ③ 0xAA 0xEE : Displays that the Frame locates in tail.
- ④ If any of the Frame data is '0xAA', '0xAA' should be added right after it. (byte stuffing)
- ⑤ If any data following '0xAA' is not '0xAA', '0xCC' or '0xEE', it is the situation that an error has occurred.

Detailed **Frame Data** is configured as follows:

Slave ID	Frame type	Data	CRC	
1 byte	1 byte	0~248 bytes.	2 bytes	
			Low byte	High byte

- ① Slave ID : Ezi-MOTIONLINK-Plus-R number (0~15) connected to the PC communication port.
- ② Frame type : To designate command type of relevant frames. For the command type, refer to 「1-2-1. Frame Type and Data Configuration」section.
- ③ Data : Data structure and length is set according to Frame type. For more information, refer to 「1-2-1. Frame Type and Data Configuration」section.
- ④ CRC : To check that an error occurs during communication, '0xA001' of a polynomial factor in **CRC16(Cyclic Redundancy Check)** is used. Or 'X16+X15+X2+1' of a polynomial factor in CRC-16-IBM (Cyclic Redundancy Check) is used. CRC calculation is performed for all items (Slave ID, Frame type, Data) prior to CRC item.

## 1-1-3. CRC Calculation Example

The following program source is included in a file (file name : CRC\_Checksum.c) provided with the product.

1)'0xA001'of CRC16

```

const unsigned short TABLE_CRCVALUE[] =
{
    0X0000, 0XC0C1, 0XC181, 0X0140, 0XC301, 0X03C0, 0X0280, 0XC241,
    0XC601, 0X06C0, 0X0780, 0XC741, 0X0500, 0XC5C1, 0XC481, 0X0440,
    0XCC01, 0X0CC0, 0X0D80, 0XCD41, 0X0F00, 0XCFC1, 0XCE81, 0X0E40,
    0X0A00, 0XCAC1, 0XCB81, 0X0B40, 0XC901, 0X09C0, 0X0880, 0XC841,
    0XD801, 0X18C0, 0X1980, 0XD941, 0X1B00, 0XDBC1, 0XDA81, 0X1A40,
    0X1E00, 0XDEC1, 0XDF81, 0X1F40, 0XDD01, 0X1DC0, 0X1C80, 0XDC41,
    0X1400, 0XD4C1, 0XD581, 0X1540, 0XD701, 0X17C0, 0X1680, 0XD641,
    0XD201, 0X12C0, 0X1380, 0XD341, 0X1100, 0XD1C1, 0XD081, 0X1040,
    0XF001, 0X30C0, 0X3180, 0XF141, 0X3300, 0XF3C1, 0XF281, 0X3240,
    0X3600, 0XF6C1, 0XF781, 0X3740, 0XF501, 0X35C0, 0X3480, 0XF441,
    0X3C00, 0XFCC1, 0XFD81, 0X3D40, 0XFF01, 0X3FC0, 0X3E80, 0XFE41,
    0XFA01, 0X3AC0, 0X3B80, 0XFB41, 0X3900, 0XF9C1, 0XF881, 0X3840,
    0X2800, 0XE8C1, 0XE981, 0X2940, 0XEB01, 0X2BC0, 0X2A80, 0XEA41,
    0XEE01, 0X2EC0, 0X2F80, 0XEF41, 0X2D00, 0XEDC1, 0XEC81, 0X2C40,
    0XE401, 0X24C0, 0X2580, 0XE541, 0X2700, 0XE7C1, 0XE681, 0X2640,
    0X2200, 0XE2C1, 0XE381, 0X2340, 0XE101, 0X21C0, 0X2080, 0XE041,
    0XA001, 0X60C0, 0X6180, 0XA141, 0X6300, 0XA3C1, 0XA281, 0X6240,
    0X6600, 0XA6C1, 0XA781, 0X6740, 0XA501, 0X65C0, 0X6480, 0XA441,
    0X6C00, 0XACC1, 0XAD81, 0X6D40, 0XAF01, 0X6FC0, 0X6E80, 0XAE41,
    0XAA01, 0X6AC0, 0X6B80, 0XAB41, 0X6900, 0XA9C1, 0XA881, 0X6840,
    0X7800, 0XB8C1, 0XB981, 0X7940, 0XBB01, 0X7BC0, 0X7A80, 0XBA41,
    0XBE01, 0X7EC0, 0X7F80, 0XBF41, 0X7D00, 0XBDC1, 0XBC81, 0X7C40,
    0XB401, 0X74C0, 0X7580, 0XB541, 0X7700, 0XB7C1, 0XB681, 0X7640,
    0X7200, 0XB2C1, 0XB381, 0X7340, 0XB101, 0X71C0, 0X7080, 0XB041,
    0X5000, 0X90C1, 0X9181, 0X5140, 0X9301, 0X53C0, 0X5280, 0X9241,
    0X9601, 0X56C0, 0X5780, 0X9741, 0X5500, 0X95C1, 0X9481, 0X5440,
    0X9C01, 0X5CC0, 0X5D80, 0X9D41, 0X5F00, 0X9FC1, 0X9E81, 0X5E40,
    0X5A00, 0X9AC1, 0X9B81, 0X5B40, 0X9901, 0X59C0, 0X5880, 0X9841,
    0X8801, 0X48C0, 0X4980, 0X8941, 0X4B00, 0X8BC1, 0X8A81, 0X4A40,
    0X4E00, 0X8EC1, 0X8F81, 0X4F40, 0X8D01, 0X4DC0, 0X4C80, 0X8C41,
    0X4400, 0X84C1, 0X8581, 0X4540, 0X8701, 0X47C0, 0X4680, 0X8641,
    0X8201, 0X42C0, 0X4380, 0X8341, 0X4100, 0X81C1, 0X8081, 0X4040
};

```

```

unsigned short CalcCRC(unsigned char* pDataBuffer, unsigned long usDataLen)
{
    unsigned char nTemp;
    unsigned short wCRCWord = 0xFFFF;

    while (usDataLen--)
    {
        nTemp = wCRCWord ^ *(pDataBuffer++);
        wCRCWord >>= 8;
        wCRCWord ^= TABLE_CRCVALUE[nTemp];
    }
    return wCRCWord;
}

```

2) 'X16+X15+X2+1' of CRC-16-IBM

```

unsigned short CalcCRCbyAlgorithm(unsigned char* pDataBuffer, unsigned long usDataLen)
{
    const unsigned short POLYNOMIAL = 0xA001;
    unsigned short wCrc;
    int iByte, iBit;

    /* Initialize CRC */
    wCrc = 0xffff;

    for (iByte = 0; iByte < usDataLen; iByte++)
    {
        /* Exclusive-OR the byte with the CRC */
        wCrc ^= *(pDataBuffer + iByte);

        /* Loop through all 8 data bits */

        for (iBit = 0; iBit <= 7; iBit++)
        {
            /* If the LSB is 1, shift the CRC and XOR the polynomial mask with the CRC */

            // Note - the bit test is performed before the rotation, so can't move the << here
            if (wCrc & 0x0001)
            {
                wCrc >>= 1;
                wCrc ^= POLYNOMIAL;
            }
            else
            {
                // Just rotate it
                wCrc >>= 1;
            }
        }
    }
    return wCrc;
}

```

#### 1-1-4. Response Frame Structure and Communication Error (Ver6)

When any command is sent, the basic structure of Frame at the response side is same. However, there is a difference in case of **Frame Data**, which 'communication status' is added as shown below.

Slave ID	Frame Type	Data		CRC	
1 byte	1 byte	1 byte	0~247 bytes	2 bytes	
		Communication status	Response data	Low byte	High byte


- ① Slave ID : Same to sending Frame.  
(When this is not same to sending data, it should be recognized as the error status.)
- ② Frame type : Same to sending Frame.

(When this is not same to sending data, it should be recognized as the error status.)

- ③ Data : When simple executive instructions are sent, this data cannot be read. However, in case of response, 1 byte is added to display the communication status (error / normal).

The code by bytes means the '**Communication status**' as follows.

Hexa Code	Decimal Code	Description
0x00	0	Communication is normal.
0x80	128	Frame Type Error : Responded Frame type cannot be recognized.
0x81	129	Data error, ROM data read/write error : Data value responded is without the given range.
0x82	130	Received Frame Error : Frame data received is out of this specification.
0x85	133	Running Command Failure : The user has tried to execute new running commands in wrong condition as follows. 1) currently motor is running 2) currently motor is stopping 3) currently Servo is OFF status 4) try to Z-pulse Origin without external encoder 5) other wrong motion command
0x86	134	RESET Failure : The user has tried to execute new running in condition as follows. 1) While the servo is ON 2) Already RESET in ON by external input signal
0x87	135	Servo ON Failure ① : While an alarm occurs, the user has tried to execute Servo ON command.
0x88	136	Servo ON Failure ② : While Emergency Stop occurs, the user has tried to execute Servo ON command.
0x89	137	Servo ON Failure ③ : 'ServoON' signal is assigned to external input signal already. Servo ON/OFF can execute by external input signal only.
0xAA	170	CRC Error : Frame data received is occurred CRC error by noise influence, etc. In this case, DLL Library of sending side automatically try to send 1 more time.

 <b>Caution</b>	1) If 'Header' and 'Slave ID' values in the sending Frame are abnormal, there is no response from the product. 2) If the communication status is displayed to '130', the size of response data is '0' byte.
--	--



## 1 – 2. Structure of Frame

### 1 – 2 – 1. Frame type and Data Configuration

(1) The following table displays the content and configuration of data by Frame type.

(7) The following table shows the content and configuration of data by frame type.

Frame Type	Library Name	Contents						
0x01 (1)	FAS_ GetSlaveInfo	<p>Connected slave type and program version information are required.</p> <p>Sending : 0 byte Response : 1~248 bytes</p> <table><tr><td>1 byte</td><td>1 bytes</td><td>0~246 bytes</td></tr><tr><td>Communication status</td><td>Slave type</td><td>ACII string with NULL byte ( strlen() + 1 bytes)</td></tr></table> <p>◆ Slave type : 11 : Ezi-MOTIONLINK-Plus-R</p>	1 byte	1 bytes	0~246 bytes	Communication status	Slave type	ACII string with NULL byte ( strlen() + 1 bytes)
1 byte	1 bytes	0~246 bytes						
Communication status	Slave type	ACII string with NULL byte ( strlen() + 1 bytes)						
0x10 (16)	FAS_ SaveAllParameters	<p>Current setting parameters &amp; assign of IO signals are saved in the ROM of Ezi-MOTIONLINK-Plus-R. Even though the product is powered off, saving these must be possible. (Values set at 'FAS_SetParameter' &amp; 'FAS_SetIOAssignMap' are saved together.)</p> <p>Sending : 0 byte Response : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	1 byte	Communication status				
1 byte								
Communication status								
0x11 (17)	FAS_ GetRomParameter	<p>Specific parameter values in the ROM are read.</p> <p>Sending : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>Parameter number (0~32)</td></tr></table> <p>Response : 5 bytes</p> <table><tr><td>1 byte</td><td>4 bytes</td></tr><tr><td>Communication status</td><td>Parameter value</td></tr></table> <p>Refer to 「1-2-2. Parameter List」</p>	1 byte	Parameter number (0~32)	1 byte	4 bytes	Communication status	Parameter value
1 byte								
Parameter number (0~32)								
1 byte	4 bytes							
Communication status	Parameter value							
0x12 (18)	FAS_ SetParameter	<p>Specific parameter values are saved to the RAM of Ezi-MOTIONLINK-Plus-R.</p> <p>Sending : 5 bytes</p> <table><tr><td>1 byte</td><td>4 bytes</td></tr><tr><td>Parameter number (0~32)</td><td>Parameter value</td></tr></table> <p>Response : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table> <p>Refer to 「1-2-2. Parameter List」</p>	1 byte	4 bytes	Parameter number (0~32)	Parameter value	1 byte	Communication status
1 byte	4 bytes							
Parameter number (0~32)	Parameter value							
1 byte								
Communication status								

0x13 (19)	FAS_ GetParameter	<p>Specific parameter values in the RAM are read</p> <p>Sending : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>Parameter number (0~32)</td></tr></table> <p>Response : 5 bytes</p> <table><tr><td>1 byte</td><td>4 bytes</td></tr><tr><td>Communication status</td><td>Parameter value</td></tr></table> <p>Refer to 「1-2-2. Parameter List」</p>	1 byte	Parameter number (0~32)	1 byte	4 bytes	Communication status	Parameter value
1 byte								
Parameter number (0~32)								
1 byte	4 bytes							
Communication status	Parameter value							
0x20 (32)	FAS_ SetIOOutput	<p>Output signal level of the control output port is set.</p> <p>Sending : 8 bytes</p> <table><tr><td>4 bytes</td><td>4 bytes</td></tr><tr><td>I/O set mask value</td><td>I/O clear mask value</td></tr></table> <p>When specific bit of the set mask is '1', the relevant output port signal is set to [ON]. When specific bit of the clear mask is '1', the relevant output port signal is set to [OFF]. For more information, refer to 「1-2-3. Bit setup of Output Pin」.</p> <p>Response : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	4 bytes	4 bytes	I/O set mask value	I/O clear mask value	1 byte	Communication status
4 bytes	4 bytes							
I/O set mask value	I/O clear mask value							
1 byte								
Communication status								
0x21 (33)	FAS_ SetIOInput	<p>Input signal level of the control input port is set.</p> <p>Sending : 8 bytes</p> <table><tr><td>4 bytes</td><td>4 bytes</td></tr><tr><td>I/O set mask value</td><td>I/O clear mask value</td></tr></table> <p>When specific bit of the set mask is '1', the relevant input port signal is set to [ON]. When specific bit of the clear mask is '1', the relevant input port signal is set to [OFF]. For more information, refer to 「1-2-4. Bit setup of Input Pin」.</p> <p>Response : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	4 bytes	4 bytes	I/O set mask value	I/O clear mask value	1 byte	Communication status
4 bytes	4 bytes							
I/O set mask value	I/O clear mask value							
1 byte								
Communication status								

0x22 (34)	FAS_ GetIOInput	<p>Current input signal status of the control input port is read.</p> <p>Sending : 0 byte</p> <p>Response : 5 byte</p> <table><tr><td>1 byte</td><td>4 bytes</td></tr><tr><td>Communication status</td><td>Input status value</td></tr></table> <p>Relevant bit by each input signal, refer to 「1-2-4. Bit setup of Input Pin」.</p>	1 byte	4 bytes	Communication status	Input status value				
1 byte	4 bytes									
Communication status	Input status value									
0x23 (35)	FAS_ GetIOOutput	<p>Current output signal status of the control output port is read.</p> <p>Sending : 0 byte</p> <p>Response : 5 byte</p> <table><tr><td>1 byte</td><td>4 bytes</td></tr><tr><td>Communication status</td><td>Output status value</td></tr></table> <p>Relevant bit by each output signal, refer to 「1-2-3. Bit setup of Output Pin」.</p>	1 byte	4 bytes	Communication status	Output status value				
1 byte	4 bytes									
Communication status	Output status value									
0x24 (36)	FAS_ SetIOAssignMap	<p>To assign control I/O signals to the pin of CN1 port and set the signal level. By running 'FAS_SaveAllParameters', you can save the setting value to the ROM.</p> <p>Sending : 6 bytes</p> <table><tr><td>1 byte</td><td>4 bytes</td><td>1 byte</td></tr><tr><td>I/O number</td><td>I/O pin masking data</td><td>Setting level</td></tr></table> <p>◆I/O number: '0~11' corresponds to 'Limit+, Limit-, Org, IN1,..., IN9' respectively, and '12~22' corresponds to 'COMP, OUT1,..., OUT9' respectively.</p> <p>◆I/O pin masking data: Refer to 「1-2-4. Bit setup of Input Pin」.</p> <p>◆Level Setting: 0: Active Low, 1:Active High</p> <p>Response : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	1 byte	4 bytes	1 byte	I/O number	I/O pin masking data	Setting level	1 byte	Communication status
1 byte	4 bytes	1 byte								
I/O number	I/O pin masking data	Setting level								
1 byte										
Communication status										
0x25 (37)	FAS_ GetIOAssignMap	<p>I/O setting status of CN3 is read.</p> <p>Sending : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>I/O number</td></tr></table> <p>◆I/O number: '0~7' corresponds to 'Limit+, Limit-, Org, IN1, ..., IN5' respectively, and '8~11' corresponds to 'COMP, OUT1, ..., OUT3' respectively.</p> <p>Response : 6 bytes</p> <table><tr><td>1 byte</td><td>4 bytes</td><td>1 byte</td></tr><tr><td>Communication status</td><td>IO pin masking status</td><td>Level status</td></tr></table> <p>For more information, refer to '0x24'Frame type.</p>	1 byte	I/O number	1 byte	4 bytes	1 byte	Communication status	IO pin masking status	Level status
1 byte										
I/O number										
1 byte	4 bytes	1 byte								
Communication status	IO pin masking status	Level status								

0x26 (38)	FAS_ IOAssignMapReadR OM	Control I/O setting status and signal level setting value are read from ROM area.  Sending : 0 byte Response : 2 bytes <table><tr><td>1 byte</td><td>1 byte</td></tr><tr><td>Communication status</td><td>Command performing status (0 : complete, values except 0: error)</td></tr></table>	1 byte	1 byte	Communication status	Command performing status (0 : complete, values except 0: error)												
1 byte	1 byte																	
Communication status	Command performing status (0 : complete, values except 0: error)																	
0x27 (39)	FAS_ TriggerOutput_Run A	To occur a command for 'Compare Out' signal  Sending : 18 bytes <table><tr><td>1 byte</td><td>4 bytes</td><td>4 bytes</td></tr><tr><td>Output start/stop command (1:start 0:stop)</td><td>Pulse start position [pulse]</td><td>Pulse period [pulse]</td></tr></table> <table><tr><td>4 bytes</td><td>1 byte</td><td>4 bytes</td></tr><tr><td>Pulse width [msec]</td><td>Output pin number (fix to 0)</td><td>spare</td></tr></table> ◆ Pulse start position: Setting the start position of first pulse output. (-134,217,727 ~134,217,727) ◆ Pulse period: Setting the pulse period. (0: pulse output only 1 time in pulse start position 1~134,217,727 : pulse output repeatedly depends on setting) ◆ Pulse width: Setting the pulse width. (1~1000)  Response : 2 bytes <table><tr><td>1 byte</td><td>1 byte</td></tr><tr><td>Communication status</td><td>Command performing status (0: complete, values except 0: error)</td></tr></table>	1 byte	4 bytes	4 bytes	Output start/stop command (1:start 0:stop)	Pulse start position [pulse]	Pulse period [pulse]	4 bytes	1 byte	4 bytes	Pulse width [msec]	Output pin number (fix to 0)	spare	1 byte	1 byte	Communication status	Command performing status (0: complete, values except 0: error)
1 byte	4 bytes	4 bytes																
Output start/stop command (1:start 0:stop)	Pulse start position [pulse]	Pulse period [pulse]																
4 bytes	1 byte	4 bytes																
Pulse width [msec]	Output pin number (fix to 0)	spare																
1 byte	1 byte																	
Communication status	Command performing status (0: complete, values except 0: error)																	
0x28 (40)	FAS_ TriggerOutput_Stat us	Command to check if the trigger output pulse is working or not.  Sending : 0 byte Response : 2 bytes <table><tr><td>1 byte</td><td>1 byte</td></tr><tr><td>Communication status</td><td>Status (1 :output ON, 0 :output OFF)</td></tr></table>	1 byte	1 byte	Communication status	Status (1 :output ON, 0 :output OFF)												
1 byte	1 byte																	
Communication status	Status (1 :output ON, 0 :output OFF)																	
0x2A (42)	FAS_ ServoEnable	Set Servo ON/OFF status.  Sending : 1 byte <table><tr><td>1 byte</td></tr><tr><td>0:OFF, 1:ON</td></tr></table> Response : 1 byte <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	1 byte	0:OFF, 1:ON	1 byte	Communication status												
1 byte																		
0:OFF, 1:ON																		
1 byte																		
Communication status																		

0x2B (43)	FAS_ ServoAlarmReset	Reset Servo alarm status.  Sending : 0 byte Response : 1 byte <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	1 byte	Communication status				
1 byte								
Communication status								
0x31 (49)	FAS_ MoveStop	To request to stop running the motor  Sending : 0 byte Response : 1 byte <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	1 byte	Communication status				
1 byte								
Communication status								
0x32 (50)	FAS_ EmergencyStop	To request the running motor to stop emergently  Sending : 0 byte Response : 1 byte <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	1 byte	Communication status				
1 byte								
Communication status								
0x33 (51)	FAS_ MoveOriginSingleAxis	To request the motor to return to the origin at the current setting parameter condition  Sending : 0 byte Response : 1 byte <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	1 byte	Communication status				
1 byte								
Communication status								
0x34 (52)	FAS_ MoveSingleAxisAbsPositions	To request the motor to move its position as much as the absolute value[pulse]  Sending : 8 bytes <table><tr><td>4 bytes</td><td>4 bytes</td></tr><tr><td>Absolute position value</td><td>Running speed [pps]</td></tr></table> Response : 1 byte <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	4 bytes	4 bytes	Absolute position value	Running speed [pps]	1 byte	Communication status
4 bytes	4 bytes							
Absolute position value	Running speed [pps]							
1 byte								
Communication status								
0x35 (53)	FAS_ MoveSingleAxisIncPositions	To request the motor to move its position as much as the incremental value[pulse]  Sending : 8 bytes <table><tr><td>4 bytes</td><td>4 bytes</td></tr><tr><td>Incremental position value</td><td>Running speed [pps]</td></tr></table> Response : 1 byte <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	4 bytes	4 bytes	Incremental position value	Running speed [pps]	1 byte	Communication status
4 bytes	4 bytes							
Incremental position value	Running speed [pps]							
1 byte								
Communication status								

0x36 (54)	FAS_ MoveToLimit	<p>To request the motor to start limit motion at the current setting parameter condition</p> <p>Sending : 5 bytes</p> <table><tr><td>4 bytes</td><td>1 byte</td></tr><tr><td>Running speed [pps]</td><td>Running direction (0: -Limit 1: +Limit)</td></tr></table> <p>Response : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	4 bytes	1 byte	Running speed [pps]	Running direction (0: -Limit 1: +Limit)	1 byte	Communication status
4 bytes	1 byte							
Running speed [pps]	Running direction (0: -Limit 1: +Limit)							
1 byte								
Communication status								
0x37 (55)	FAS_ MoveVelocity	<p>To request the motor to start Jog motion at the current setting parameter condition</p> <p>Sending : 5 bytes</p> <table><tr><td>4 bytes</td><td>1 byte</td></tr><tr><td>Running speed [pps]</td><td>Running direction (0: -Jog 1: +Jog)</td></tr></table> <p>Response : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	4 bytes	1 byte	Running speed [pps]	Running direction (0: -Jog 1: +Jog)	1 byte	Communication status
4 bytes	1 byte							
Running speed [pps]	Running direction (0: -Jog 1: +Jog)							
1 byte								
Communication status								
0x38 (56)	FAS_ PositionAbsOverride	<p>To request the motor to change the target absolute position value[pulse] while it is in running.</p> <p>Sending : 4 bytes</p> <table><tr><td>4 bytes</td></tr><tr><td>Changed command position value [pulse]</td></tr></table> <p>Response : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	4 bytes	Changed command position value [pulse]	1 byte	Communication status		
4 bytes								
Changed command position value [pulse]								
1 byte								
Communication status								
0x39 (57)	FAS_ PositionIncOverride	<p>To request the motor to change the target incremental position value[pulse] while it is in running.</p> <p>Sending : 4 bytes</p> <table><tr><td>4 bytes</td></tr><tr><td>Changed command position value [pulse]</td></tr></table> <p>Response : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	4 bytes	Changed command position value [pulse]	1 byte	Communication status		
4 bytes								
Changed command position value [pulse]								
1 byte								
Communication status								

0x3A (58)	FAS_ VelocityOverride	<p>To request the motor to change the running speed value[pps] while it is in running.</p> <p>Sending : 4 bytes</p> <table><tr><td>4 bytes</td></tr><tr><td>Changed running speed [pps]</td></tr></table> <p>The accel/decel time is assigned to 'Axis Acc Time' and 'Axis Dec Time' value in parameter lists.</p> <p>Response : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	4 bytes	Changed running speed [pps]	1 byte	Communication status
4 bytes						
Changed running speed [pps]						
1 byte						
Communication status						
0x3B (59)	FAS_ AllMoveStop	<p>To request stop for all motor that connected in same port.</p> <p>Sending : 0 byte (Slave number must be '99')</p> <p>Response : no response (Can not get a reply from all slave at the same time. So all slave does not send a response.)</p>				
0x3C (60)	FAS_ AllEmergencyStop	<p>To request emergency stop for all motor that connected in same port.</p> <p>Sending : 0 byte (Slave number must be '99')</p> <p>Response : no response (Can not get a reply from all slave at the same time. So all slave does not send a response.)</p>				
0x3D (61)	FAS_All MoveOriginSingleAxis	<p>To request return to the origin at the current setting parameter condition for all motors that connected in same port.</p> <p>Sending : 0 byte ( Slave number must be '99')</p> <p>Response : no response (Can not get a reply from all slave at the same time. So all slave does not send a response.)</p>				
0x3E (62)	FAS_All SingleAxisAbsPos	<p>To request move its position as much as the absolute value[pulse] for all motors that connected in same port.</p> <p>Sending : 8 bytes ( Slave number must be '99')</p> <table><tr><td>4 bytes</td><td>4 bytes</td></tr><tr><td>Absolute position value</td><td>Running speed [pps]</td></tr></table> <p>Response : no response (Can not get a reply from all slave at the same time. So all slave does not send a response.)</p>	4 bytes	4 bytes	Absolute position value	Running speed [pps]
4 bytes	4 bytes					
Absolute position value	Running speed [pps]					

0x3F (63)	FAS_All SingleAxisIncPos	<p>To request move its position as much as the incremental value[pulse] for all motors that connected in same port.</p> <p>Sending : 8 bytes ( Slave number must be '99')</p> <table><tr><td>4 bytes</td><td>4 bytes</td></tr><tr><td>Incremental position value</td><td>Running speed [pps]</td></tr></table> <p>Response : no response (Can not get a reply from all slave at the same time. So all slave does not send a response.)</p>	4 bytes	4 bytes	Incremental position value	Running speed [pps]								
4 bytes	4 bytes													
Incremental position value	Running speed [pps]													
0x80 (128)	FAS_ MoveSingleAxisAbs PosEx	<p>Request the motor to move its position as much as the absolute value[pulse] with Custom Accel. / Decel. Time[msec]</p> <p>Sending: 40 bytes</p> <table><tr><td>4 bytes</td><td>4 bytes</td><td>4 bytes</td><td>2 bytes</td></tr><tr><td>Absolute position value</td><td>Running speed [pps]</td><td>Flag option</td><td>Custom Accel. Time (1~9999)</td></tr></table> <table><tr><td>2 bytes</td><td>24 bytes</td></tr><tr><td>Custom Decel. Time (1~9999)</td><td>Reserved</td></tr></table> <p>Flag ooption : 0x0001 : reserved 0x0002 : Custom Accel. Time is used. 0x0004 : Custom Decel. Time is used.</p> <p>If the Flag bit is OFF status(0), Accel./Decel. Time value is used that saved in controller.</p> <p>Response: 1 byte</p>	4 bytes	4 bytes	4 bytes	2 bytes	Absolute position value	Running speed [pps]	Flag option	Custom Accel. Time (1~9999)	2 bytes	24 bytes	Custom Decel. Time (1~9999)	Reserved
4 bytes	4 bytes	4 bytes	2 bytes											
Absolute position value	Running speed [pps]	Flag option	Custom Accel. Time (1~9999)											
2 bytes	24 bytes													
Custom Decel. Time (1~9999)	Reserved													
0x81 (129)	FAS_ MoveSingleAxisIncP osEx	<p>Request the motor to move its position as much as the absolute value[pulse] with Custom Accel. / Decel. Time[msec]</p> <p>Sending: 40 bytes</p> <table><tr><td>4 bytes</td><td>4 bytes</td><td>4 bytes</td><td>2 bytes</td></tr><tr><td>incremental position value</td><td>Running speed [pps]</td><td>Flag option</td><td>Custom Accel. Time (1~9999)</td></tr></table> <table><tr><td>2 bytes</td><td>24 bytes</td></tr><tr><td>Custom Decel. Time (1~9999)</td><td>Reserved</td></tr></table> <p>Flag option : 0x0001 : reserved 0x0002 : Custom Accel. Time is used. 0x0004 : Custom Decel. Time is used.</p> <p>If the Flag bit is OFF status(0), Accel./Decel. Time value is used that saved in controller.</p> <p>Response: 1 byte</p>	4 bytes	4 bytes	4 bytes	2 bytes	incremental position value	Running speed [pps]	Flag option	Custom Accel. Time (1~9999)	2 bytes	24 bytes	Custom Decel. Time (1~9999)	Reserved
4 bytes	4 bytes	4 bytes	2 bytes											
incremental position value	Running speed [pps]	Flag option	Custom Accel. Time (1~9999)											
2 bytes	24 bytes													
Custom Decel. Time (1~9999)	Reserved													



0x82 (130)	FAS_ MoveVelocityEx	<p>Request to start Jog movement with acceleration value[msec].</p> <p>Sending: 37 bytes</p> <table><tr><td>4 bytes</td><td>1 byte</td><td>4 bytes</td></tr><tr><td>Running speed [pps]</td><td>Running direction (0: -Jog 1: +Jog)</td><td>Flag option</td></tr></table> <table><tr><td>2 bytes</td><td>26 bytes</td></tr><tr><td>Custom Accel./Decel. Time (1~9999)</td><td>Reserved</td></tr></table> <p>Flag option : 0x0001 : reserved 0x0002 : Custom Accel./Decel. Time is used.</p> <p>If the Flag bit is OFF status(0), Accel./Decel. Time value is used that saved in controller.</p> <p>Response : 1 byte</p>	4 bytes	1 byte	4 bytes	Running speed [pps]	Running direction (0: -Jog 1: +Jog)	Flag option	2 bytes	26 bytes	Custom Accel./Decel. Time (1~9999)	Reserved
4 bytes	1 byte	4 bytes										
Running speed [pps]	Running direction (0: -Jog 1: +Jog)	Flag option										
2 bytes	26 bytes											
Custom Accel./Decel. Time (1~9999)	Reserved											
0x70	FAS_MoveLinearAbs Pos	<p>To request Linear Interpolation move its position as much as the absolute value[pulse] for more than 2 motors that connected in same port.</p> <p>The position value is ins absolute value[pulse].</p> <p>Refer to 「2. Library for PC program(Ver6)」.</p>										
0x71	FAS_MoveLinearInc Pos	<p>To request Linear Interpolation move its position as much as the incremental value[pulse] for more than 2 motors that connected in same port.</p> <p>The position value is ins incremental value[pulse].</p> <p>Refer to 「2. Library for PC program(Ver6)」.</p>										
0x40 (64)	FAS_ GetAxisStatus	<p>To request the Flag value of displaying the running status</p> <p>Sending : 0 byte Response : 5 bytes</p> <table><tr><td>1 byte</td><td>4 bytes</td></tr><tr><td>Communication status</td><td>Status flag value</td></tr></table> <p>For bit related to each Flag, refer to 「1-2-5. Bit setup of Status Flag」.</p>	1 byte	4 bytes	Communication status	Status flag value						
1 byte	4 bytes											
Communication status	Status flag value											
0x41 (65)	FAS_ GetIOAxisStatus	<p>To request the I/O status and the running Flag status. (Frame type 0x22, 0x23, and 0x40 are packed.)</p> <p>Sending : 0 byte Response : 13 bytes</p> <table><tr><td>1 byte</td><td>4 bytes</td><td>4 bytes</td><td>4 bytes</td></tr><tr><td>Communication status</td><td>Input status value</td><td>Output status value</td><td>Status flag value</td></tr></table>	1 byte	4 bytes	4 bytes	4 bytes	Communication status	Input status value	Output status value	Status flag value		
1 byte	4 bytes	4 bytes	4 bytes									
Communication status	Input status value	Output status value	Status flag value									

0x42 (66)	FAS_ GetMotionStatus	<p>To request the current running progress status and its PT number (Frame type 0x51, 0x53, 0x54, and 0x55 are packed.)</p> <p>Sending : 0 byte Response : 21 bytes</p> <table><tr><td>1 byte</td><td>4 bytes</td><td>4 bytes</td><td>4 bytes</td><td>4 bytes</td><td>4 bytes</td></tr><tr><td>Communication status</td><td>Command position value</td><td>Actual Position value</td><td>Position Difference value</td><td>Running speed value</td><td>Current running PT number</td></tr></table>	1 byte	4 bytes	4 bytes	4 bytes	4 bytes	4 bytes	Communication status	Command position value	Actual Position value	Position Difference value	Running speed value	Current running PT number						
1 byte	4 bytes	4 bytes	4 bytes	4 bytes	4 bytes															
Communication status	Command position value	Actual Position value	Position Difference value	Running speed value	Current running PT number															
0x43 (67)	FAS_ GetAllStatus	<p>To request all data including the current running status (Frame type 0x41, and 0x42 are packed.)</p> <p>Sending : 0 byte Response : 33 bytes</p> <table><tr><td>1 byte</td><td>4 bytes</td><td>4 bytes</td><td>4 bytes</td></tr><tr><td>Communication status</td><td>Input status value</td><td>Output status value</td><td>Status flag value</td></tr></table> <table><tr><td>4 bytes</td><td>4 bytes</td><td>4 bytes</td><td>4 bytes</td><td>4 bytes</td></tr><tr><td>Command position value</td><td>Actual position value</td><td>Position Difference value</td><td>Running speed value</td><td>Reserved</td></tr></table>	1 byte	4 bytes	4 bytes	4 bytes	Communication status	Input status value	Output status value	Status flag value	4 bytes	4 bytes	4 bytes	4 bytes	4 bytes	Command position value	Actual position value	Position Difference value	Running speed value	Reserved
1 byte	4 bytes	4 bytes	4 bytes																	
Communication status	Input status value	Output status value	Status flag value																	
4 bytes	4 bytes	4 bytes	4 bytes	4 bytes																
Command position value	Actual position value	Position Difference value	Running speed value	Reserved																
0x50 (80)	FAS_ SetCommandPos	<p>The command position value is continuously updated during operation. It is allowed to check the change of the command position value after setting this command position before starting operation.</p> <p>Sending : 4 bytes</p> <table><tr><td>4 bytes</td></tr><tr><td>Command position setting count value</td></tr></table> <p>Response : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	4 bytes	Command position setting count value	1 byte	Communication status														
4 bytes																				
Command position setting count value																				
1 byte																				
Communication status																				
0x51 (81)	FAS_ GetCommandPos	<p>To request the command position value[pulse] being tracked.</p> <p>Sending : 0 byte Response : 5 bytes</p> <table><tr><td>1 byte</td><td>4 bytes</td></tr><tr><td>Communication status</td><td>Command position value</td></tr></table>	1 byte	4 bytes	Communication status	Command position value														
1 byte	4 bytes																			
Communication status	Command position value																			

0x52 (82)	FAS_ SetActualPos	<p>If Encoder feedback is used, the actual position value is continuously updated during operation. The actual position can be set to this value before starting operation to check the actual position value.</p> <p>Sending : 4 bytes</p> <table><tr><td>4 bytes</td></tr><tr><td>Actual position count value</td></tr></table> <p>Response : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	4 bytes	Actual position count value	1 byte	Communication status
4 bytes						
Actual position count value						
1 byte						
Communication status						
0x53 (83)	FAS_ GetActualPos	<p>To request the current actual position value[pulse].</p> <p>Sending : 0 byte</p> <p>Response : 5 bytes</p> <table><tr><td>1 byte</td><td>4 bytes</td></tr><tr><td>Communication status</td><td>Actual position value</td></tr></table>	1 byte	4 bytes	Communication status	Actual position value
1 byte	4 bytes					
Communication status	Actual position value					
0x54 (84)	FAS_ GetPosError	<p>To request the difference[pulse] between the command position value and the actual position value.</p> <p>Sending : 0 byte</p> <p>Response : 5 bytes</p> <table><tr><td>1 byte</td><td>4 bytes</td></tr><tr><td>Communication status</td><td>Position difference value</td></tr></table> <p>By this value, the user can check the current running status (how much inposition is tracked).</p>	1 byte	4 bytes	Communication status	Position difference value
1 byte	4 bytes					
Communication status	Position difference value					
0x55 (85)	FAS_ GetActualVel	<p>To request the current running speed value [pps]</p> <p>Sending : 0 byte</p> <p>Response : 5 bytes</p> <table><tr><td>1 byte</td><td>4 bytes</td></tr><tr><td>Communication status</td><td>Speed value</td></tr></table>	1 byte	4 bytes	Communication status	Speed value
1 byte	4 bytes					
Communication status	Speed value					
0x56 (86)	FAS_ ClearPosition	<p>Ezi-MOTIONLINK Plus-R is closed-loop controlled, so the command position value is continuously updated during operation. This command position and actual position value set (Actual position) to '0' before starting operation.</p> <p>Sending : 0 byte</p> <p>Response : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	1 byte	Communication status		
1 byte						
Communication status						

0x58 (88)	FAS_ MovePause	<p>To request the pause start and pause end of motor motioning.</p> <p>Sending : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>0:pause release, 1:pause start</td></tr></table> <p>Response : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>Communication status</td></tr></table>	1 byte	0:pause release, 1:pause start	1 byte	Communication status				
1 byte										
0:pause release, 1:pause start										
1 byte										
Communication status										
0x60 (96)	FAS_ PosTableReadItem	<p>To read PT values in the RAM of the drive.</p> <p>Sending : 2 bytes</p> <table><tr><td>2 bytes</td></tr><tr><td>Readable PT No. (0~255)</td></tr></table> <p>Response : 65 bytes</p> <table><tr><td>1 byte</td><td>64 bytes</td></tr><tr><td>Communication Status</td><td>Relevant PT value</td></tr></table> <p>For items by each PT, refer to 「1-2-6. Position Table Item」.</p>	2 bytes	Readable PT No. (0~255)	1 byte	64 bytes	Communication Status	Relevant PT value		
2 bytes										
Readable PT No. (0~255)										
1 byte	64 bytes									
Communication Status	Relevant PT value									
0x61 (97)	FAS_ PosTableWriteItem	<p>To save PT values to the RAM of the drive.</p> <p>Sending : 66 bytes</p> <table><tr><td>2 bytes</td><td>64 bytes</td></tr><tr><td>PT No. (0~255)</td><td>Relevant PT value</td></tr></table> <p>For items by each PT, refer to 「1-2-6. Position Table Item」.</p> <p>Response : 2 bytes</p> <table><tr><td>1 byte</td><td>1 byte</td></tr><tr><td>Communication Status</td><td>Command performing status (values except 0 : complete, 0: error)</td></tr></table>	2 bytes	64 bytes	PT No. (0~255)	Relevant PT value	1 byte	1 byte	Communication Status	Command performing status (values except 0 : complete, 0: error)
2 bytes	64 bytes									
PT No. (0~255)	Relevant PT value									
1 byte	1 byte									
Communication Status	Command performing status (values except 0 : complete, 0: error)									
0x62 (98)	FAS_ PosTableReadROM	<p>To read all PT values (256) in the ROM of the drive.</p> <p>Sending : 0 byte</p> <p>Response : 2 bytes</p> <table><tr><td>1 byte</td><td>1 byte</td></tr><tr><td>Communication Status</td><td>Command performing status (0: complete, values except 0: error)</td></tr></table>	1 byte	1 byte	Communication Status	Command performing status (0: complete, values except 0: error)				
1 byte	1 byte									
Communication Status	Command performing status (0: complete, values except 0: error)									
0x63 (99)	FAS_ PosTableWriteROM	<p>To save all PT value(256) to the ROM of the drive.</p> <p>Sending : 0 byte</p> <p>Response : 2 bytes</p>								

		<table><tr><td>1 byte</td><td>1 byte</td></tr><tr><td>Communication Status</td><td>Command performing status (0: complete, values except 0: error)</td></tr></table>	1 byte	1 byte	Communication Status	Command performing status (0: complete, values except 0: error)						
1 byte	1 byte											
Communication Status	Command performing status (0: complete, values except 0: error)											
0x64 (100)	FAS_ PosTableRunItem	<p>To start the position table operation from the designated PT number.</p> <p>Sending : 2 bytes</p> <table><tr><td>2 bytes</td></tr><tr><td>PT No. (0~255)</td></tr></table> <p>Response : 1 byte</p> <table><tr><td>1 byte</td></tr><tr><td>Communication Status</td></tr></table>	2 bytes	PT No. (0~255)	1 byte	Communication Status						
2 bytes												
PT No. (0~255)												
1 byte												
Communication Status												
0x6A (106)	FAS_ PosTableReadOneItem	<p>To read specific values of PT items in the RAM of the drive.</p> <p>Sending : 4 bytes</p> <table><tr><td>2 bytes</td><td>2 bytes</td></tr><tr><td>PT No. to read (0~255)</td><td>Offset value of the specific item to read (0~40)</td></tr></table> <p>Refer to 「1-2-6. Position Table Item」 for Offset value.</p> <p>Response : 5 bytes</p> <table><tr><td>1 byte</td><td>4 bytes</td></tr><tr><td>Communication Status</td><td>Relevant one of PT value</td></tr></table>	2 bytes	2 bytes	PT No. to read (0~255)	Offset value of the specific item to read (0~40)	1 byte	4 bytes	Communication Status	Relevant one of PT value		
2 bytes	2 bytes											
PT No. to read (0~255)	Offset value of the specific item to read (0~40)											
1 byte	4 bytes											
Communication Status	Relevant one of PT value											
0x6B (107)	FAS_ PosTableWriteOneItem	<p>To save specific values of PT items in the RAM of the drive.</p> <p>Sending : 8 bytes</p> <table><tr><td>2 bytes</td><td>2bytes</td><td>4 bytes</td></tr><tr><td>PT No. To save(0~255)</td><td>Offset value of the specific item to save (0~40)</td><td>Stored value</td></tr></table> <p>Refer to 「1-2-6. Position Table Item」 for Offset value.</p> <p>Response : 2 bytes</p> <table><tr><td>1 byte</td><td>1 byte</td></tr><tr><td>Communication Status</td><td>Command performing status (values except 0: complete, 0: error)</td></tr></table>	2 bytes	2bytes	4 bytes	PT No. To save(0~255)	Offset value of the specific item to save (0~40)	Stored value	1 byte	1 byte	Communication Status	Command performing status (values except 0: complete, 0: error)
2 bytes	2bytes	4 bytes										
PT No. To save(0~255)	Offset value of the specific item to save (0~40)	Stored value										
1 byte	1 byte											
Communication Status	Command performing status (values except 0: complete, 0: error)											

\* Frame Type '0x65' ~ '0x69', '0x90' ~ '0x92' are allotted for internal use.

## 1-2-2. Parameter Lists

No.	Name	Unit	Lower	Upper	Default
0	Encoder Multiply		0	3	3
1	Axis Max Speed	[pps]	1	2,500,000	500,000
2	Axis Start Speed	[pps]	1	2,500,000	1
3	Axis Acc Time	[msec]	1	9,999	100
4	Axis Dec Time	[msec]	1	9,999	100
5	Speed Override	[%]	1	500	100
6	Jog Speed	[pps]	1	2,500,000	5,000
7	Jog Start Speed	[pps]	1	2,500,000	1
8	Jog Acc Dec Time	[msec]	1	9,999	100
9* <sup>1</sup>	S/W Limit Plus Value	[pulse]	-134,217,728	134,217,727	134,217,727
10* <sup>1</sup>	S/W Limit Minus Value	[pulse]	-134,217,728	134,217,727	-134,217,728
11	S/W Limit Stop Method		0	1	0
12	H/W Limit Stop Method		0	1	0
13	Limit Sensor Logic		0	1	0
14	Org Speed	[pps]	1	2,500,000	5,000
15	Org Search Speed	[pps]	1	2,500,000	1,000
16	Org Acc Dec Time	[msec]	1	9,999	50
17	Org Method		0	5	0
18	Org Direction		0	1	1
19* <sup>1</sup>	Org OffSet	[pulse]	-134,217,728	134,217,727	0
20* <sup>1</sup>	Org Position Set	[pulse]	-134,217,728	134,217,727	0
21	Org Sensor Logic		0	1	0
22	Limit Sensor Direction		0	1	0
23	Pulse Type		0	1	1
24	Encoder Direction		0	1	0
25	Motion Direction		0	1	0
26	Servo Alarmreset Logic		0	1	0
27	Servo On Output Logic		0	1	0
28	Servo Alarm Logic		0	1	1
29	Servo Inposition Logic		0	1	0
30* <sup>2</sup>	Servo Alarmreset On Time	msec	10	1000	10
31* <sup>2</sup>	Use Motion Queue		0	1	0
32* <sup>2</sup>	Motion Profile		0	1	0
33* <sup>2</sup>	Origin Search OK Flag Off		0	3	0

\*<sup>1</sup> The parameter range differs from the product version, listed as below.

V06.03.04x.xx : -134,217,728 ~134,217,727

V06.03.05x.xx : - 2,147,483,648 ~ 2,147,483,647

\*<sup>2</sup> The parameter is available from the product version V06.03.0xx.28 and above.

### 1-2-3. Bit setting of the control output pin

This displays the detailed description for 0x20 Frame type.

This command is applicable only to 3 signals of 'User Output 0' ~ 'User Output 2' out of 24 signal types in the control output port. The rest (15 output signals) of them cannot be operated by the user's disposal. When any relevant situation occurs while Ezi-MOTIONLINK-Plus-R operates, they are displayed. The following table shows bit mask values by each signal.

Signal Name	Relevant Bit Position	Signal Name	Relevant Bit Position	Signal Name	Relevant Bit Position
Compare Out	0x00000001	Origin Search OK	0x00000100	User OUT 1	0x00010000
Inposition	0x00000002	Reserved	0x00000200	User OUT 2	0x00020000
Alarm	0x00000004	Reserved	0x00000400	Reserved	0x00040000
Moving	0x00000008	Reserved	0x00000800	Reserved	0x00080000
Acc/Dec	0x00000010	Reserved	0x00001000	Reserved	0x00100000
Reserved	0x00000020	Reserved	0x00002000	Reserved	0x00200000
Reserved	0x00000040	Reserved	0x00004000	Reserved	0x00400000
Reserved	0x00000080	User OUT 0	0x00008000	Reserved	0x00800000

【Example 1】 Sending data to turn ON the User Output 2 port.

4 bytes (I/O set mask value)	4 bytes (I/O clear mask value)
0x00020000	0x00000000

【Example 2】 Sending data to turn OFF the User Output 2 port

4 bytes (I/O set mask value)	4 bytes (I/O clear mask value)
0x00000000	0x00020000

## 1-2-4. Bit setting of the control input pin

This displays the detailed description for 0x21 Frame type.

This command is applicable to 32 signals in the control input port. The user can use signals for test as if they are inputted without actual input signal. The following table shows bit mask values by each signal.

Signal Name	Relevant Bit Position	Signal Name	Relevant Bit Position	Signal Name	Relevant Bit Position	Signal Name	Relevant Bit Position
Limit+	0x00000001	PT A4	0x00000100	Alarm Reset	0x00010000	JPT input2	0x01000000
Limit-	0x00000002	PT A5	0x00000200	ServoON	0x00020000	JPT Start	0x02000000
Origin	0x00000004	PT A6	0x00000400	Pause	0x00040000	User IN 0	0x04000000
Clear Position	0x00000008	PT A7	0x00000800	Org Search	0x00080000	User IN 1	0x08000000
PT A0	0x00000010	PT Start	0x00001000	Teaching	0x00100000	User IN 2	0x10000000
PT A1	0x00000020	Stop	0x00002000	E-stop	0x00200000	User IN 3	0x20000000
PT A2	0x00000040	Jog+	0x00004000	JPT input0	0x00400000	User IN 4	0x40000000
PT A3	0x00000080	Jog-	0x00008000	JPT input1	0x00800000	Reserved	0x80000000

【Example 1】 Sending data to turn ON the Clear Position port

4 bytes (I/O set mask value)	4 bytes (I/O clear mask value)
0x00000004	0x00000000

【Example 2】 Sending data to turn OFF the Clear Position port

4 bytes (I/O set mask value)	4 bytes ( I/O clear mask value)
0x00000000	0x00000004



## 1–2–5. Bit setting of Status Flag

Refer to 'motion\_define.h' of include files.

Name of Flag Define	Contents	Relevant Bit Position
FFLAG_ERRORALL	One or more error occurs.	0X00000001
FFLAG_HWPOSILMT	'+' direction limit sensor turns ON.	0X00000002
FFLAG_HWNEGALMT	'-' direction limit sensor turns ON.	0X00000004
FFLAG_SWPOGILMT	'+' direction program limit is exceeded.	0X00000008
FFLAG_SWNEGALMT	'-' direction program limit is exceeded.	0X00000010
Reserved1		0X00000020
Reserved2		0X00000040
Reserved3		0X00000080
Reserved4		0X00000100
Reserved5		0X00000200
Reserved6		0X00000400
Reserved7		0X00000800
Reserved8		0X00001000
Reserved9		0X00002000
Reserved10		0X00004000
Reserved11		0X00008000
FFLAG_EMGSTOP	The motor is under emergency stop.	0X00010000
FFLAG_SLOWSTOP	The motor is under general stop.	0X00020000
FFLAG_ORIGINRETURNING	The motor is returning to the origin.	0X00040000
FFLAG_INPOSITION	Inposition has been finished.	0X00080000
FFLAG_SERVOON	The motor is under Servo ON.	0X00100000
FFLAG_ALARMRESET	AlarmReset has run.	0X00200000
Reserved12		0X00400000
FFLAG_ORIGINSENSOR	The origin sensor is ON.	0X00800000
FFLAG_ZPULSE	Operation of z-pulse method during zero return operation	0X01000000
FFLAG_ORIGINRETOK	Origin return operation has been finished.	0X02000000
FFLAG_MOTIONDIR	To display the motor operating direction (+: OFF, -: ON)	0X04000000
FFLAG_MOTIONING	The motor is running.	0X08000000
FFLAG_MOTIONPAUSE	The motor in running is stopped by Pause command.	0X10000000
FFLAG_MOTIONACCEL	The motor is operating to the acceleration section.	0X20000000
FFLAG_MOTIONDECEL	The motor is operating to the deceleration section.	0X40000000
FFLAG_MOTIONCONST	The motor is operating to the normal speed, not acceleration / deceleration sections.	0X80000000

## 1–2–6. Bit setting of Status Flag

Refer to 'motion\_define.h' of include files.

Refer to 'motion\_define.h' among the include file.

Name	Name of structure paramater	Number of Byte	Offset value	Unit	Low Limit	Upper Limit
Position <sup>*1</sup>	lPosition	4 (signed)	0	[pulse]	-2,147,483,648	2,147,483,647
Low Speed	dwStartSpd	4 (unsigned)	4	[pps]	0	2,500,000
High Speed	dwMoveSpd	4 (unsigned)	8	[pps]	0	2,500,000
Accel. Time	wAccelRate	2 (unsigned)	12	[msec]	1	9,999
Decel. Time	wDecelRate	2 (unsigned)	14	[msec]	1	9,999
Command	wCommand	2 (unsigned)	16		0	10
Wait time	wWaitTime	2 (unsigned)	18	[msec]	0	600,000
Continuous Action	wContinuous	2 (unsigned)	20		0	1
Jump Table No.	wBranch	2 (unsigned)	22		0 10,000	255 10,255
Jump PT 0	wCond_branch0	2 (unsigned)	24		0 10,000	255 10,255
Jump PT 1	wCond_branch1	2 (unsigned)	26		0 10,000	255 10,255
Jump PT 2	wCond_branch2	2 (unsigned)	28		0 10,000	255 10,255
Loop Count	wLoopCount	2 (unsigned)	30		0	100
Loop Jump Table No.	wBranchAfterLoop	2 (unsigned)	32		0 10,000	255 10,255
PT set	wPTSet	2 (unsigned)	34		0	15
Loop Counter Clear	wLoopCountCLR	2 (unsigned)	36		0	255
Check Inposition	bCheckInpos	2 (unsigned)	38		0	1
Compare Position	lTriggerPos	4 (signed)	40	[pulse]	-134,217,728	+134,217,727

Compare Width	wTriggerOnTime	2 (unsigned)	44	[msec]	1	9,999
Reserved		2 (unsigned)	46	[%]	20	90
Reserved		4 (unsigned)	48	[pps]	0	33,333
Reserved		4 (signed)	52	[pulse]	-134,217,728	+134,217,727
Reserved		2 (unsigned)	56		0	10,000
Blank		6 (unsigned)	58	0x00		

\*1 The parameter range differs from the product version, listed as below.

V06.03.04x.xx : -134,217,728 ~134,217,727

V06.03.05x.xx : - 2,147,483,648 ~ 2,147,483,647

For the setting method by each item, refer to 「[User Manual-Position Table](#)」.

## 1 – 3. Program Method

There are 2 method of programming for Ezi-MOTIONLINK-Plus-R.

The first and commonly used method is using Visual C++ language under window system of PC.

Library that offered together with Ezi-MotionLink-PR has to be used. Refer to

[「2. Library for PC Program\(Ver6\)」](#)

The second method can be accomplished by sending command characters directly to Ezi-MOTIONLINK-Plus-R. The user has to prepare low level protocol programming like 'Protocol Test' program. This method is normally used for PLC system.

The specific program method can be tested using the user GUI program called 'ProtocolTest\_PlusR.exe' provided with the product. Refer to [「 3. Protocol for PLC Program」](#).

## 2 . Library for PC Program(Ver6)

### 2－1. Library Configuration

To use this library, C++ header file(\*.h) and library file(\*.lib or \*.dll) are required. These files are included in "[WWFASTECH\WWEziMOTION PlusR\WWinclude\WWFAS\\_EziMotionPlusR.h](#)". The following contents should be included in a source file for development.

```
#include "WWFASTECH\WWEziMOTION PlusR\WWinclude\WWFAS\_EziMotionPlusR.h"
#include "WWFASTECH\WWEziMOTION PlusR\WWinclude\WWCOMM\_Define.h"
#include "WWFASTECH\WWEziMOTION PlusR\WWinclude\WWMOTION\_DEFINE.h"
#include "WWFASTECH\WWEziMOTION PlusR\WWinclude\WWReturnCodes\_Define.h"
```

Also, library files are as follows:

```
"WWFASTECH\WWEziMOTION PlusR\WWinclude\WWEziMotionPlusR.lib"
"WWFASTECH\WWEziMOTION PlusR\WWinclude\WWEziMotionPlusR.dll"
```

A sample program source of using library is included in a "[WWFASTECH\WWEziMOTION PlusR\WWExamples\WW](#)" folder.

(1) The following table describes values returned when each library(DLL) function is used. **The user can check the values returned at the library(DLL) function.** In the case of programming method using a protocol, this service not provided.

Item	Definition	Returned Value	Description
Normal	FMM_OK	0	The function has normally performed the command.
Input Error	FMM_NOT_OPEN	1	Wrong port number is inputted.
	FMM_INVALID_PORT_NUM	2	The port that is not connected.
	FMM_INVALID_SLAVE_NUM	3	Wrong slave number is inputted.
Operation Error	FMM_POSTABLE_ERROR	9	An error occurs while the motor accesses to the position table.
Connection Error	FMC_DISCONNECTED	5	The relevant product is disconnected.
	FMC_TIMEOUT_ERROR	6	Response delay(100 msec) occurs.
	FMC_CRCFAILED_ERROR	7	Checksum error occurs.
	FMC_RECVPACKET_ERROR	8	Protocol level error occurs in packet that comes from Product.

(2) The following table shows return values included commonly in all libraries. **The user can check the result (communication status, running status) judged by the product.** When the user develops programs by using protocols or libraries(DLL), they are available as well.


Item	Description	Returned Value	Description
Normal	FMP_OK	0	Communication has been normally performed.
Input Error	FMP_FRAMETYPEERROR	128	The product cannot recognize the command.
	FMP_DATAERROR	129	Input data is out of the range.

Operation Error	FMP_RUNFAIL	133	The motor is already running or not prepared for running. Other wrong motion command.
	FMP_RESETFAIL	134	The user cannot execute AlarmReset command while the servo is ON.
	FMP_SERVOONFAIL1	135	An alarm has occurred.
	FMP_SERVOONFAIL2	136	The motor is under Emergency Stop.
	FMP_SERVOONFAIL3	137	'ServoON'signal is already assigned to input pin.
Connection Error	FMP_PACKETERROR	130	Protocol level error occurs in packet that Product's received.
	FMP_PACKETCRCERROR	170	CRC value is not correct in packet that Product's received.


## 2-2. Communication Status Window

Above communication status is divide by 3 groups.


### (1) Communication Error



COM Port is not connected. (Does not occur on GUI)



COM Port number of inputted number is not a connected Port. (Does not occur on GUI)




FMM\_INVALID\_SLAVE\_NUM,

Slave number does not exist. (Does not occur on GUI)




FMC\_DISCONNECTED = 5,

COM Port is a disconnect.




FMC\_TIMEOUT\_ERROR,

There is no response from the product.




FMC\_CRCFAILED\_ERROR,

CRC value of communication packet from the product is not correct.




FMC\_RECVPACKET\_ERROR,

The length of received packet is not correct.




FMP\_FRAMETYPEERROR = 0x80,

Product do not recognize the command or wrong command is sended.



FMP\_DATAERROR,


The value of the sent data is out of the proper range for product.



FMP\_PACKETERROR,

Received Frame is the data which not suit as standard.(The length of received packet on product is not correct.)






FMP\_PACKETCRCERROR = 0xAA,

CRC calculation of Packet sent to Drive does not correct.


## (2) Wrong Command



FMP\_RUNFAIL = 0x85,

Fail on motion command : The motor can not run on next status.

- The motor is already running
- The motor is under stop command
- Servo OFF status
- Try to Z-pulse Origin without external encoder (only for Ezi-STEP)
- other wrong motion command



FMP\_RESETFAIL,


Fail on reset command : The motor can not reset on next status.

- Servo ON status
- Already 'Reset' status by external input signal.




FMP\_SERVOONFAIL1,

Wrong 'Servo ON' command during Alarm happens.



FMP\_SERVOONFAIL2,

Wrong 'Servo ON' command during E-Stop happens.



FMP\_SERVOONFAIL3,

'Servo ON' Signal is assigned by external input pin. In this case Servo ON command by DLL library is not working.

## 2 – 3. Communication Link Function

Function Name	Description
<b>FAS_Connect</b>	The product tries to connect communication with Ezi-MOTIONLINK-Plus-R: When it is successfully connected, TRUE will return. Otherwise, FALSE will return.
<b>FAS_Close</b>	The product tries to disconnect communication with Ezi-MOTIONLINK-Plus-R.
<b>FAS_GetSlaveInfo</b>	Ezi-MOTIONLINK-Plus-R reads product type and program version: Product type and version information will return.
<b>FAS_IsSlaveExist</b>	Ezi-MOTIONLINK-Plus-R checks(with FAS_Connect) whether there is the relevant Ezi-MOTIONLINK-Plus-R. When it exists, TRUE will return. Otherwise, FALSE will return.
<b>FAS_EnableLog</b>	To control the communication error log function : When it exists, TRUE will return. Otherwise, FALSE will return.
<b>FAS_SetLogPath</b>	To set the saved folder name of error log file : When folder exists, TRUE will return. Otherwise, FALSE will return.

## FAS\_Connect

FAS\_Connect is the function of connecting Ezi-MotionLink-PR.

Syntax

```
BOOL FAS_Connect(
    BYTE nPortNo,
    DWORD dwBaud
);
```

Parameters

*nPortNo*

Select a serial port to be connected.

*dwBaud*

Input the Baudrate of the serial port.

Return Value

When it is successfully connected, TRUE will returns. Otherwise, FALSE will return.

Remarks

Example

```
#include "FAS_EziMOTIONPlusR.h"

void funcInit()
{
    BYTE nPortNo = 1; // COMM Port Number
    DWORD dwBaudrate = 115200; // Baudrate. (Be variable by setting)
    BYTE iSlaveNo = 0; // Slave No (0 ~ 15)
    char lpBuff[256];
    int nBuffSize = 256;
    BYTE nType;
    int nRtn;

    // Try to connect
    if (FAS_Connect(nPortNo, dwBaudrate) == FALSE)
    {
        // Connection failed.
        // The port is not connected or the baudrate may be wrong.
        return;
    }

    if (FAS_IsSlaveExist(nPortNo, iSlaveNo) == FALSE)
    {
        // There is no relevant slave number.
        // Check the slave number of Ezi-SERVO Plus-R.
        return;
    }

    nRtn = FAS_GetSlaveInfo(nPortNo, iSlaveNo, &nType, lpBuff, nBuffSize);
```

```
if (nRtn != FMM_OK)
{
    // Command has not been performed properly.
    // Refer to ReturnCodes_Define.h.
}

printf("Port : %d (Slave %d) \n", nPortNo, iSlaveNo);
printf("\tType : %d \n", nType);
printf("\tVersion : %d \n", lpBuff);

// Disconnect.
FAS_Close(nPortNo);
}
```

See Also

FAS\_Close

## FAS\_Close

---

To disconnect the serial port being used

### Syntax

```
void FAS_Close(  
    BYTE nPortNo  
);
```

### Parameters

*nPortNo*

Port number to disconnect

### Remarks

### Example

Refer to 'FAS\_Connect' library.

### See Also

FAS\_Connect

## FAS\_GetSlaveInfo

---

To get the version information string of the relevant product

### Syntax

```
int FAS_GetSlaveInfo(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    BYTE pType,  
    LPSTR lpBuff,  
    int nBuffSize  
);
```

### Parameters

*nPortNo*

Port number of relevant product

*iSlaveNo*

Slave number of relevant product

*pType*

Relevant product type number

*lpBuff*

Buffer pointer to get version information string

*nBuffSize*

lpBuff memory allocation size

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no product of iSlaveNo in the relevant port.

### Remarks

### Example

Refer to 'FAS\_Connect' library.

### See Also

## FAS\_IsSlaveExist

---

To check that the product is connected

### Syntax

```
BOOL FAS_IsSlaveExist(  
    BYTE nPortNo,  
    BYTE iSlaveNo  
);
```

### Parameters

*nPortNo*

Port number of relevant product

*iSlaveNo*

Slave number of relevant product

### Return Value

TRUE : The product is connected.

FALSE : The product is disconnected.

### Remarks

This function is provided from the library only and it is inapplicable to the protocol program mode.

### Example

Refer to 'FAS\_Connect' library.

### See Also

FAS\_Connect



## FAS\_EnableLog

---

To control the save function of communication error log file.

### Syntax

```
void FAS_EnableLog(BOOL bEnable);
```

### Parameters

*bEnable*

Select output of Log.

### Remarks

Select the Log output during Ezi-MOITON Plus-R function used. This setup

Do not affect the other process or other program.

Log function start from 'FAS\_Connect' function, the Log output is end when the 'FAS\_Close' is excuted. Basig setting value of Log output is TRUE.

### Example

```
#include "FAS_ EziMOTIONPlusR.h"

void funcDisableLog()
{
    BYTE nPortNo = 1;    // COMM Port No.

    FAS_EnableLog(FALSE);

    // After this, the Logs of the functions are not output.

    // Try to connect.
    if (FAS_Connect(nPortNo, 115200) == FALSE)
    {
        // connection fail.
        // cab be different Port or different Baudrate.
        return;
    }

    // Connection close.
```

```
        FAS_Close(nPortNo);  
    }
```

See Also

FAS\_SetLogPath

## FAS\_SetLogPath

---

Setup the folder path of Log output files.

Syntax

```
BOOL FAS_SetLogPath(LPCTSTR lpPath);
```

Parameters

*lpPath*

Absolute path string where log will be saved.

Return Value

If the folder name does not exist or can not access, return FALSE.

Remarks

This function has to be called before using FAS\_Connect library.

If the lpPath value is NULL or the length is 0, the Log path is selected to Ezi-MOTION Plus-R Library folder. The default value for Log path is NULL that the current library and program exist folder.

Example

```
#include "FAS_ EziMOTIONPlusR.h"
```

```
void funcEnableLog()
{
    BYTE nPortNo = 1; // COMM Port number

    // Log output.
    FAS_EnableLog(TRUE);

    if (!FAS_SetLogPath(_T("C:\\Logs\\"))) // C:\\Logs folder exist.
    {
        // Log path does not exist.
        Return;
    }

    // All Log output is stored in C:\\Logs folder.

    // Try to connect.
    if (FAS_Connect(nPortNo, 115200) == FALSE)
    {
        // Connection fail.
        // cab be different Port or different Baudrate.
        return;
    }

    // Close connect.
    FAS_Close(nPortNo);
}
```

See Also

FAS\_EnableLog

## 2 – 4. Parameter Control Function

Function Name	Description
<b>FAS_SaveAllParameters</b>	Current parameters are saved to the ROM: Even after the product is powered OFF, parameters related to operating speed, acceleration/deceleration time, and origin return need to be preserved.
<b>FAS_SetParameter</b>	The designated parameter is saved to the RAM: Specific parameter is saved.
<b>FAS_GetParameter</b>	The designated parameter is read from the RAM: Specific parameter is read.
<b>FAS_GetROMParameter</b>	The designated parameter is read from the ROM: Specific parameter is read from the ROM.

## FAS\_SaveAllParameters

---

All parameters edited up to now & assign status of In/Out signals are saved in the ROM area.

### Syntax

```
Int FAS_SaveAllParameters(  
    BYTE nPortNo,  
    BYTE iSlaveNo  
);
```

### Parameters

*nPortNo*

Port number of relevant product

*iSlaveNo*

Slave number of relevant product

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no product of iSlaveNo in the relevant port.

### Remarks

Parameter values set to 'FAS\_SetIOAssignMap' library as well as current parameter values are saved to the ROM.

### Example

```
#include "FAS_ EziMOTIONPlusR.h"  
  
void funcModifyParameter()  
{  
    BYTE nPortNo = 1; // COMM Port Number  
    BYTE iSlaveNo = 0; // Slave No (0 ~ 15)  
    long lParamVal;  
    int nRtn;  
  
    // Try to connect  
    if (FAS_Connect(nPortNo, 115200) == FALSE)  
    {  
        // Connection failed.  
        // The port is not connected or the baudrate may be wrong.  
        return;  
    }  
}
```

```

// Check Axis Start Speed Parameter.
nRtn = FAS_GetParameter(nPortNo, iSlaveNo, SERVO_AXISSTARTSPEED, &IParamVal);
if (nRtn != FMM_OK)
{
    // Command has not been performed properly.
    // Refer to ReturnCodes_Define.h.
    _ASSERT(FALSE);
}
else
{
    // Parameter value saved in current product.
    printf("Parameter [before] : Start Speed = %d \r\n", IParamVal);
}

// Change Start Speed parameter as 200 then read it again.
nRtn = FAS_SetParameter(nPortNo, iSlaveNo, SERVO_AXISSTARTSPEED, 200);
_ASSERT(nRtn == FMM_OK); // It will stop if the command didn't execute correctly.

nRtn = FAS_GetParameter(nPortNo, iSlaveNo, SERVO_AXISSTARTSPEED, &IParamVal);
_ASSERT(nRtn == FMM_OK);
printf("Parameter [after] : Start Speed = %d \r\n", IParamVal);

// Check the value saved in the ROM.
nRtn = FAS_GetROMParameter(nPortNo, iSlaveNo, SERVO_AXISSTARTSPEED, &IParamVal);
_ASSERT(nRtn == FMM_OK); // It will stop if the command didn't execute correctly.
printf("Parameter [ROM] : Start Speed = %d \r\n", IParamVal);

// Edit the parameter value then save it in the ROM.
nRtn = FAS_SetParameter(nPortNo, iSlaveNo, SERVO_AXISSTARTSPEED, 100);
_ASSERT(nRtn == FMM_OK); // It will stop if the command didn't execute correctly.
nRtn = FAS_SaveAllParameters(nPortNo, iSlaveNo);
_ASSERT(nRtn == FMM_OK);

// Disconnect.
FAS_Close(nPortNo);
}

```

See Also

FAS\_GetRomParameter

## FAS\_SetParameter

---

Edit the relevant parameter value and then save it to the RAM.

### Syntax

```
int FAS_SetParameter(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    BYTE iParamNo,  
    long lParamValue  
);
```

### Parameters

*nPortNo*

Port number of relevant product

*iSlaveNo*

Slave number of relevant product

*iParamNo*

Parameter number to be edited

*lParamValue*

Parameter value to be edited

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no product of iSlaveNo in the relevant port.

FMM\_INVALID\_PARAMETER\_NUM : There is no parameter of designated iParamNo.

### Remarks

The function operates only for one parameter designated.

Parameters in the product are saved to 2 memory areas. That is, when power is off, the ROM saves parameters permanently. When power is on, parameters in the ROM are copied to the DSP RAM and used. When the user changes parameters, it changes not parameters in the ROM but parameter in the RAM. This function is to set the parameter number designated from the RAM to the relevant value.

### Example

Refer to 'FAS\_SaveAllParameter' library.

### See Also

FAS\_GetParameter

## FAS\_GetParamater

---

To call specific parameter values of the product

### Syntax

```
int FAS_GetParameter(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    BYTE iParamNo,  
    long* IParamValue  
);
```

### Parameters

*nPortNo*

Port number of relevant product

*iSlaveNo*

Slave number of relevant product

*iParamNo*

Parameter number to be imported

*IParamValue*

Parameter values

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no product of iSlaveNo in the relevant port.

FMM\_INVALID\_PARAMETER\_NUM : There is no parameter of designated iParamNo.

### Remarks

The function operates only for one parameter designated.

Parameters in the product are saved to 2 memory areas. That is, when power is off, the ROM saves parameters permanently. When power is on, parameters in the ROM are copied to the DSP RAM and used. When the user changes parameters, it changes not parameters in the ROM but parameter in the RAM. This function reads the parameter number designated to the RAM.

### Example

Refer to 'FAS\_SaveAllParameter' library.

### See Also

FAS\_SetParameter



## FAS\_GetROMParameter

---

To call parameters saved in the ROM

### Syntax

```
int FAS_GetROMParameter(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    BYTE iParamNo,  
    long* IRomParam  
);
```

### Parameters

*nPortNo*

Port number of relevant product

*iSlaveNo*

Slave number of relevant product

*iParamNo*

Parameter number to be imported

*IRomParam*

Parameter values saved in the ROM

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no product of iSlaveNo in the relevant port.

FMM\_INVALID\_PARAMETER\_NUM : There is no parameter of designated iParamNo.

### Remarks

To call parameter values saved in the ROM

Even though this function runs, the value in the RAM is not changed. For this, run FAS\_SetParameter.

### Example

Refer to 'FAS\_SaveAllParameter' library.

### See Also

FAS\_SaveAllParameters

## 2 – 5. Servo Control Function

Function Name	Description
<b>FAS_ServoEnable</b>	The Servo status of the product designated turns ON/OFF.
<b>FAS_ServoAlarmReset</b>	The product which an alarm occurs is released: Troubleshoot the alarm cause and use this function.

## FAS\_ServoEnable

To turn ON/OFF the product servo

Syntax

```
int FAS_ServoEnable(
    BYTE nPortNo,
    BYTE iSlaveNo,
    BOOL bOnOff
);
```

Parameters

*nPortNo*  
Port number of relevant product  
*iSlaveNo*  
Slave number of relevant  
*bOnOff*  
Enable or Disable.

Return Value

FMM\_OK : Command has been normally performed.  
FMM\_NOT\_OPEN : The product has not been connected yet.  
FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.  
FMM\_INVALID\_SLAVE\_NUM : There is no product of iSlaveNo in the relevant port.

Remarks

The given time is required until Servo ON flag in the axis status turns on after enable.

Example

```
#include "FAS_ EziMOTIONPlusR.h"

void funcAxisStatus()
{
    BYTE nPortNo = 1; // COMM Port Number
    BYTE iSlaveNo = 0; // Slave No (0 ~ 15)
    EZISERVO_AXISSTATUS AxisStatus;
    int nRtn;

    // Try to connect
    if (FAS_Connect(nPortNo, 115200) == FALSE)
    {
        // Connection failed.
        // The port is not connected or the baudrate may be wrong.
        return;
    }

    nRtn = FAS_GetAxisStatus(nPortNo, iSlaveNo, &(AxisStatus.dwValue));
    _ASSERT(nRtn == FMM_OK);

    // If SERVO_ON flag turns off, the servo turns on.
    if (AxisStatus.FFLAG_SERVOON == 0)
    {
```

```
        nRtn = FAS_ServoEnable(nPortNo, iSlaveNo, TRUE);
        _ASSERT(nRtn == FMM_OK);
    }

    // If there is an alarm, AlarmReset runs.
    if (AxisStatus.FFLAG_ERRORALL || AxisStatus.FFLAG_ERROVERCURRENT ||
AxisStatus.FFLAG_ERROVERLOAD)
    {
        nRtn = FAS_ServoAlarmReset(nPortNo, iSlaveNo);
        _ASSERT(nRtn == FMM_OK);
    }

    // Disconnect.
    FAS_Close(nPortNo);
}
```

See Also

FAS\_ServoAlarmReset

## FAS\_ServoAlarmReset

---

To send AlarmReset command

### Syntax

```
int FAS_ServoAlarmReset(  
    BYTE nPortNo,  
    BYTE iSlaveNo  
);
```

### Parameters

*nPortNo*

Port number of relevant product

*iSlaveNo*

Slave number of relevant product

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no product of iSlaveNo in the relevant port.

### Remarks

Before sending this command, troubleshoot the alarm cause.

For alarm cause, refer to 'User Manual\_Text'.

### Example

Refer to 'FAS\_ServoEnable' library

### See Also

FAS\_ServoEnable

## 2 – 6. Control I/O Function

Function Name	Description
<b>FAS_SetIOInput</b>	To set the input signal level of the control input port : Input signal is set to [ON] or [OFF].
<b>FAS_GetIOInput</b>	To read the current input signal status of the control input port : The signal status returns by bit for each input signal.
<b>FAS_SetIOOutput</b>	To set the output signal level of the control output port : Output signal is set to [ON] or [OFF].
<b>FAS_GetIOOutput</b>	To read the current output signal status of the control output port : The signal status returns by bit for each output signal.
<b>FAS_GetIOAssignMap</b>	To read the pin setting status of the CN1 port : The setting status for each 9 variable signals returns by bit to the Input and Output port.
<b>FAS_SetIOAssignMap</b>	To assign the control I/O signal to CN1 port pin and also set the signal level : Setting for each 9 variable signals is assigned to the Input and Output port.
<b>FAS_IOAssignMapReadROM</b>	To load the pin setting status of CN1 port from ROM area to RAM area.

## FAS\_SetIOInput

---

To set I/O input. For more information, refer to '1-2. Structure of Frame'.

Syntax

```
int FAS_SetIOInput(
    BYTE nPortNo,
    BYTE iSlaveNo,
    DWORD dwIOSetMask,
    DWORD dwIOCLRMask
);
```

Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*dwIOSetMask*

Input bitmask value to be set(ON)

*dwIOCLRMask*

Input bitmask value to be cleared(OFF)

Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no product of iSlaveNo in the relevant port.

Remarks

Be careful that dwIOSetMask bit and dwIOCLRMask bit are not duplicated.

Example

```
#include "FAS_ EziMOTIONPlusR.h"

void funcIO()
{
    BYTE nPortNo = 1; // COMM Port Number
    BYTE iSlaveNo = 0; // Slave No (0 ~ 15)
    DWORD dwInput, dwOutput;
    int nRtn;

    // Try to connect
    if (FAS_Connect(nPortNo, 115200) == FALSE)
```

```

{
    // Connection failed.
    // The port is not connected or the baudrate may be wrong.
    return;
}

// Check I/O input.
nRtn = FAS_GetIOInput(nPortNo, iSlaveNo, &dwInput);
_ASSERT(nRtn == FMM_OK);
if (dwInput & SERVO_IN_BITMASK_LIMITP)
{
    // Limit + input is ON.
}

if (dwInput & SERVO_IN_BITMASK_USERIN0)
{
    // User Input 0 is ON.
}

// Turning ON 'Clear Position' and 'User Input 1' inputs and turning off 'Jog +' input.
nRtn = FAS_SetIOInput(nPortNo, iSlaveNo, SERVO_IN_BITMASK_CLEARPOSITION |
SERVO_IN_BITMASK_USERIN1, SERVO_IN_BITMASK_PJOG);
_ASSERT(nRtn == FMM_OK);

// Check I/O output.
nRtn = FAS_GetIOOutput(nPortNo, iSlaveNo, &dwOutput);
_ASSERT(nRtn == FMM_OK);
if (dwOutput & SERVO_OUT_BITMASK_USEROUT0)
{
    // User Output 0 is ON.
}

// Turn off User Output 1 and 2 signals.
nRtn = FAS_SetIOOutput(nPortNo, iSlaveNo, 0, SERVO_OUT_BITMASK_USEROUT1 |
SERVO_OUT_BITMASK_USEROUT2);
_ASSERT(nRtn == FMM_OK);

// Disconnect.
FAS_Close(nPortNo);
}

```

See Also

FAS\_GetIOInput



## FAS\_GetIOInput

To read I/O input values. For more information, refer to '1-2. Structure of Frame'.

Syntax

```
int FAS_GetIOInput(
    BYTE nPortNo,
    BYTE iSlaveNo,
    DWORD* dwIOInput
);
```

Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*dwIOInput*

Parameter pointer which input values will be saved

Return Value

FMM\_OK : Command has been normally performed.


FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

Remarks

There are 8 input pins in Ezi-MOTIONLINK-Plus-R. The user can select and use 5 input pins of them. This function can read the input port status by 32bit. All of them are insulated by a photocoupler. (Refer to the figure.)



When Port A is supplied 24V from an external input port, the input is recognized to 5V(High).

### Example

Refer to 'FAS\_SetIOInput' library.

### See Also

FAS\_SetIOInput

## FAS\_SetIOOutput

To set I/O output values. For more information, refer to '1-2. Structure of Frame'.

Syntax

```
int FAS_SetIOOutput(
    BYTE nPortNo,
    BYTE iSlaveNo,
    DWORD dwIOSetMask,
    DWORD dwIOCLRMask
);
```

Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*dwIOSetMask*

Output bitmask value to be set(ON status)

*dwIOCLRMask*

Output bitmask value be cleared(OFF status)

Return Value

FMM\_OK : Command has been normally performed.


FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

Remarks

There are 4 output pins in Ezi-MOTIONLINK-Plus-R. The user can select and use 3 output pins of them.



When output data is '1', Port A becomes 0V. When it is '0', Port A becomes +5V.

Be careful that dwIOSetMask bit and dwIOCLRMask bit are not duplicated.

#### Example

Refer to FAS\_SetIOInput.

#### See Also

FAS\_GetIOOutput

## FAS\_GetIOOutput

---

To read I/O output values. For more information, refer to '1-2. Structure of Frame'.

### Syntax

```
int FAS_GetIOOutput(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    DWORD* dwIOOutput  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*dwIOInput*

Parameter pointer which the output value will be saved.

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

### Example

Refer to 'FAS\_SetIOInput' library

### See Also

FAS\_SetIOOutput

## FAS\_GetIOAssignMap

---

To read I/O Assign Map. For more information, refer to '1-2. Structure of Frame'.

Syntax

```
int FAS_GetIOAssignMap(
    BYTE nPortNo,
    BYTE iSlaveNo,
    BYTE iOPinNo,
    BYTE* nIOLogic,
    BYTE* bLevel
);
```

Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*iOPinNo*

I/O pin number to be read

*nIOLogic*

Parameter pointer which the logic value assigned to a relevant pin will be saved

*bLevel*

Parameter pointer which the active level of relevant logic will be saved

Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

Remarks

For nIOLogic, refer to 'Motion\_define.h'.

Example

```
#include "FAS_EziMOTIONPlusR.h"

void funcIOAssign()
{
    BYTE nPortNo = 1; // COMM Port Number
    BYTE iSlaveNo = 0; // Slave No (0 ~ 15)
    BYTE iPinNo;
    DWORD dwLogicMask;
    BYTE bLevel;
```

```

BYTE i;
int nRtn;

// Try to connect
if (FAS_Connect(nPortNo, 115200) == FALSE)
{
    // Connection failed.
    // The port is not connected or the baudrate may be wrong.
    return;
}

// Check assigned information of input pin.
for (i=0; i</*Input Pin Count*/12; i++)
{
    nRtn = FAS_GetIOAssignMap(nPortNo, iSlaveNo, i, &dwLogicMask, &bLevel);
    _ASSERT(nRtn == FMM_OK);

    if (dwLogicMask != IN_LOGIC_NONE)
        printf("Input Pin %d : Logic Mask 0x%08X (%s)\n", i, dwLogicMask,
((bLevel == LEVEL_LOW_ACTIVE) ? "Low Active" : "High Active"));
    else
        printf("Input Pin %d : Not assigned\n", i);
}

// Assign SERVOON Logic (Low Active) to input pin 3.
iPinNo = 3;          // 0 ~ 11 value is available (Caution : 0 ~ 2 is fixed.)
nRtn = FAS_SetIOAssignMap(nPortNo, iSlaveNo, iPinNo, SERVO_IN_BITMASK_SERVOON,
LEVEL_LOW_ACTIVE);
_ASSERT(nRtn == FMM_OK);

// Check assign information of output pin.
for (i=0; i<10/*Output Pin Count*/; i++)
{
    nRtn = FAS_GetIOAssignMap(nPortNo, iSlaveNo, 12/*Input Pin Count*/ + i,
&dwLogicMask, &bLevel);
    _ASSERT(nRtn == FMM_OK);

    if (dwLogicMask != OUT_LOGIC_NONE)
        printf("Output Pin %d : Logic Mask 0x%08X (%s)\n", i, dwLogicMask,
((bLevel == LEVEL_LOW_ACTIVE) ? "Low Active" : "High Active"));
    else
        printf("Output Pin %d : Not assigned\n", i);
}

// Assign ALARM Logic (High Active) to output pin 9.
iPinNo = 9;          // 0 ~ 9 value is available (Caution : 0 is fixed to COMPOUT.)

```

```
        nRtn = FAS_SetIOAssignMap(nPortNo, iSlaveNo, 12/*Input Pin Count*/ + iPinNo,  
SERVO_OUT_BITMASK_ALARM, LEVEL_HIGH_ACTIVE);  
        _ASSERT(nRtn == FMM_OK);  
  
        // Disconnect.  
        FAS_Close(nPortNo);  
    }
```

See Also

FAS\_SetIOAssignMap



## FAS\_SetIOAssignMap

---

To set I/O Assign Map. For more information, refer to '1-2. Structure of Frame'.

Syntax

```
int FAS_SetIOAssignMap(
    BYTE nPortNo,
    BYTE iSlaveNo,
    BYTE iOPinNo,
    BYTE nLogicNo,
    BYTE bLevel
);
```

Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*iOPinNo*

I/O Pin number to be read

*nIOLogic*

Logic value to be assigned to the relevant pin

*bLevel*

Active Level value of the relevant logic

Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

FMM\_INVALID\_PARAMETER\_NUM : Designated iOPinNo or nIOLogic value is out of range.

Remarks

To save current setting values to the ROM memory, 'FAS\_SaveAllParameters' library should be run.

Example

Refer to 'FAS\_GSetIOAssignMap' library

See Also

FAS\_GetIOAssignMap

## FAS\_IOAssignMapReadROM

---

To load the I/O setting status and signal level value being saved in ROM area

### Syntax

```
int FAS_PosTableReadROM(  
    BYTE nPortNo,  
    BYTE iSlaveNo  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

FMC\_POSTABLE\_ERROR : While reading position table, error occurred

### Remarks

### Example

### See Also

FAS\_GetIOAssignMap



## 2-7. Position Control Function

Function Name	Description
<b>FAS_SetCommandPos</b>	To set the command position value
<b>FAS_SetActualPos</b>	To set the current position to the actual position value
<b>FAS_GetCommandPos</b>	To read the current command position value
<b>FAS_GetActualPos</b>	To read the current actual position value
<b>FAS_GetPosError</b>	To read the difference between the actual position value and the command position value
<b>FAS_GetActualVel</b>	To read the actual running speed value while the motor is moving
<b>FAS_ClearPosition</b>	To set the command position and actual position value to '0'

## FAS\_SetCommandPos

---

To set the command position value to the motor

### Syntax

```
int FAS_SetCommandPos(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    long lCmdPos  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*lCmdPos*

Command position value to be set.

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

The user sets the position command (pulse output counter) value.

This function is generally used when the user sets the current position to desired coordinates.

### Example

```
#include "FAS_ EziMOTIONPlusR.h"  
  
void funcClearPosition()  
{  
    BYTE nPortNo = 1; // COMM Port Number  
    BYTE iSlaveNo = 0; // Slave No (0 ~ 15)  
    int nRtn;  
  
    // Try to connect  
    if (FAS_Connect(nPortNo, 115200) == FALSE)  
    {  
        // Connection failed.  
        // The port is not connected or the baudrate may be wrong.  
        return;  
    }  
}
```

```
// Initialize Command Position and Actual Position values to 0.  
nRtn = FAS_SetCommandPos(nPortNo, iSlaveNo, 0);  
_ASSERT(nRtn == FMM_OK);  
nRtn = FAS_SetActualPos(nPortNo, iSlaveNo, 0);  
_ASSERT(nRtn == FMM_OK);  
  
// Disconnect.  
FAS_Close(nPortNo);  
  
}
```

See Also

FAS\_SetActualPos

## FAS\_SetActualPos

---

To set the actual position value to the motor

### Syntax

```
int FAS_SetActualPos(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    long lActPos  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*lActPos*

Actual position value to be set.

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

The user sets the encoder feedback counter value to the value that he wants.

### Example

Refer to 'FAS\_GetActualPos' library.

### See Also

FAS\_SetCommandPos

## FAS\_GetCommandPos

---

To read the command position of the current motor

### Syntax

```
int FAS_GetCommandPos(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    long* lCmdPos  
);
```

### Parameters

*nPortNo*

Port number of relevant product

*iSlaveNo*

Slave number of relevant product

*lCmdPos*

Parameter pointer that command position value will be saved

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

To read the position command (pulse output counter) value.

### Example

```
#include "FAS_ EziMOTIONPlusR.h"  
  
void funcDisplayStatus()  
{  
    BYTE nPortNo = 1; // COMM Port Number  
    BYTE iSlaveNo = 0; // Slave No (0 ~ 15)  
    long lValue;  
    int nRtn;  
  
    // Try to connect  
    if (FAS_Connect(nPortNo, 115200) == FALSE)  
    {  
        // Connection failed.  
        // The port is not connected or the baudrate may be wrong.  
        return;  
    }  
}
```



```
}

// Check position information of product.
nRtn = FAS_GetCommandPos(nPortNo, iSlaveNo, &lValue);
_ASSERT(nRtn == FMM_OK);
printf("CMDPOS : %d \n", lValue);
nRtn = FAS_GetActualPos(nPortNo, iSlaveNo, &lValue);
_ASSERT(nRtn == FMM_OK);
printf("ACTPOS : %d \n", lValue);
nRtn = FAS_GetPosError(nPortNo, iSlaveNo, &lValue);
_ASSERT(nRtn == FMM_OK);
printf("POSERR : %d \n", lValue);
nRtn = FAS_GetActualVel(nPortNo, iSlaveNo, &lValue);
_ASSERT(nRtn == FMM_OK);
printf("ACTVEL : %d \n", lValue);

// Disconnect.
FAS_Close(nPortNo);
}
```

See Also

FAS\_GetActualPos

## FAS\_GetActualPos

---

To read the actual position value of the motor

### Syntax

```
int FAS_GetActualPos(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    long* lActPos  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*lActPos*

Parameter pointer which the actual position value will be saved.

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

It is mainly used to confirm the actual position after the completion of positioning.

### Example

Refer to 'FAS\_GetCommandPosition' library.

### See Also

FAS\_GetCommandPos

## FAS\_GetPosError

---

To read the position error of the motor

### Syntax

```
int FAS_GetPosError(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    long* lPosErr  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*lPosErr*

Parameter pointer which the position error value will be saved

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

### Example

Refer to 'FAS\_GetCommandPosition' library.

### See Also

FAS\_GetCommandPos,

FAS\_GetActualPos

## FAS\_GetActualVel

---

To read the actual velocity of the motor

### Syntax

```
int FAS_GetActualVel(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    long* lActVel  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*lActVel*

Parameter pointer which the actual velocity value will be saved

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

### Example

Refer to 'FAS\_GetCommandPosition' library.

### See Also

## FAS\_ClearPosition

---

To set the command position value and actual value to '0'

### Syntax

```
int FAS_SetCommandPos(  
    BYTE nPortNo,  
    BYTE iSlaveNo  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

The user sets the position command (pulse output counter) value.

This function is generally used when the user sets the current position to initial values.

### Example

```
#include "FAS_ EziMOTIONPlusR.h"  
  
void funcClearPosition()  
{  
    BYTE nPortNo = 1; // COMM Port Number
```

```
BYTE iSlaveNo = 0; // Slave No (0 ~ 15)
int nRtn;

// Try to connect
if (FAS_Connect(nPortNo, 115200) == FALSE)
{
    // Connection failed.
    // The port is not connected or the baudrate may be wrong.
    return;
}

// Initialize Command Position and Actual Position values to 0.
nRtn = FAS_ClearPosition(nPortNo, iSlaveNo);
_ASSERT(nRtn == FMM_OK);

// Disconnect.
FAS_Close(nPortNo);
}
```

See Also

FAS\_SetActualPos, FAS\_SetCommandPos

## 2－8. Status Control Function

Function Name	Description
<b>FAS_GetIOAxisStatus</b>	To read control I/O status, running status Flag value : The current input status value, the output setting status value, and the running status Flag value will return.
<b>FAS_GetMotionStatus</b>	To read the current running progress status : The command position value, the actual position value, the speed value will return.
<b>FAS_GetAllStatus</b>	To read all status including the current status at one time : This function is to combine 'FAS_GetIOAxisStatus' function and 'FAS_GetMotionStatus' function.
<b>FAS_GetAxisStatus</b>	To read the running status Flag value of the relevant Ezi-MOTIONLINK-Plus-R

## FAS\_GetIOAxisStatus

---

To read I/O Input and Output values of the relevant product, and the motor Axis Status

### Syntax

```
int FAS_GetIOAxisStatus(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    DWORD* dwInStatus,  
    DWORD* dwOutStatus,  
    DWORD* dwAxisStatus  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*dwInStatus*

Parameter pointer which the I/O input value will be saved.

*dwOutStatus*

Parameter pointer which the I/O output value will be saved.

*dwAxisStatus*

Parameter pointer which the axis status value of the relevant motor will be saved

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

### Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

### See Also



## FAS\_GetMotionStatus

---

To read the motion status of current motor at one time

Syntax

```
int FAS_GetMotionStatus(
    BYTE nPortNo,
    BYTE iSlaveNo,
    long* lCmdPos,
    long* lActPos,
    long* lPosErr,
    long* lActVel,
    WORD* wPosItemNo
);
```

Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*lCmdPos*

Parameter pointer which the command position value will be saved

*lActPos*

Parameter pointer which the actual position value will be saved.

*lPosErr*

Parameter pointer which the position error value will be saved

*lActVel*

Parameter pointer which the actual velocity value will be saved

*wPosItemNo*

Parameter pointer which current running item number in the Position Table will be saved

Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

Remarks

Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

See Also

## FAS\_GetAllStatus

To read I/O Input and Output values of the relevant product, the motor Axis Status, the motor motion status

### Syntax

```
int FAS_GetAllStatus(
    BYTE nPortNo,
    BYTE iSlaveNo,
    DWORD* dwInStatus,
    DWORD* dwOutStatus,
    DWORD* dwAxisStatus,
    long* lCmdPos,
    long* lActPos,
    long* lPosErr,
    long* lActVel,
    WORD* wPosItemNo
);
```

### Parameters

*nPortNo*  
Port number of relevant product.

*iSlaveNo*  
Slave number of relevant product.

*dwInStatus*  
Parameter pointer which the I/O input value will be saved.

*dwOutStatus*  
Parameter pointer which the I/O output value will be saved.

*dwAxisStatus*  
Parameter pointer which the axis status value of the relevant motor will be saved

*lCmdPos*  
Parameter pointer which the command position value will be saved

*lActPos*  
Parameter pointer which the actual position value will be saved

*lPosErr*  
Parameter pointer which the position error value will be saved

*lActVel*  
Parameter pointer which the actual velocity value will be saved

*wPosItemNo*  
Parameter pointer which current running item number in the Position Table will be saved

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

### Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

### See Also

FAS\_GetAxisStatus

FAS\_GetMotionStatus

## FAS\_GetAxisStatus

---

To read the motor Axis Status value. For status Flag, refer to '1-2. Structure of Frame '.

### Syntax

```
int FAS_GetAxisStatus(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    DWORD* dwAxisStatus  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*dwAxisStatus*

Parameter pointer which the axis status value of the relevant motor

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

### Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

### See Also

## 2-9. Running Control Function

Function Name	Description
<b>FAS_MoveStop</b>	The motor in running is decelerate and stopped.
<b>FAS_EmergencyStop</b>	The motor in running stops directly without deceleration
<b>FAS_MoveOriginSingleAxis</b>	The motor starts the origin return.
<b>FAS_MoveSingleAxisAbsPos</b>	The motor moves as much as the given absolute position value.
<b>FAS_MoveSingleAxisIncPos</b>	The motor moves as much as the given incremental position value.
<b>FAS_MoveToLimit</b>	The motor moves up to the position that the limit sensor is detected.
<b>FAS_MoveVelocity</b>	The motor moves to the given velocity and direction: This function is available to Jog motion.
<b>FAS_PositionAbsOverride</b>	While the motor is running, the target absolute position value [pulse] is changed.
<b>FAS_PositionIncOverride</b>	While the motor is running, the target incremental position value [pulse] is changed.
<b>FAS_VelocityOverride</b>	While the motor is running, the running velocity value [pulse] is changed.
<b>FAS_AllMoveStop</b>	All running motors that connected in same port are decelerate and stopped.
<b>FAS_AllEmergencyStop</b>	All running motors that connected in same port are directly stop without deceleration.
<b>FAS_AllMoveOriginSingleAxis</b>	All motors that connected in same port are starts the origin return.
<b>FAS_AllMoveSingleAxisAbsPos</b>	All motors that connected in same port moves as much as the given absolute position value.
<b>FAS_AllMoveSingleAxisIncPos</b>	All motors that connected in same port moves as much as the given incremental position value.
<b>FAS_MoveLinearAbsPos</b>	Between 2 motors that connected in the same port, start to Linear Interpolation operation as much as the given absolute position value.
<b>FAS_MoveLinearIncPos</b>	Between 2 motors that connected in the same port, start to Linear Interpolation operation as much as the given incremental position value.
<b>FAS_MoveLinearAbsPos2<sup>*1</sup></b>	Improved version of <b>FAS_MoveLinearAbsPos</b> . Acceleration and Deceleration were improved.
<b>FAS_MoveLinearIncPos2<sup>*1</sup></b>	Improved version of <b>FAS_MoveLinearIncPos</b> . Acceleration and Deceleration were improved.
<b>FAS_MoveSingleAxisAbsPosEx</b>	The motor moves as much as the given absolute position value

	with custom accel/decel time value.
<b>FAS_MoveSingleAxisIncPosEx</b>	The motor moves as much as the given incremental position value with custom accel/decel time value.
<b>FAS_MoveVelocityEx</b>	The motor moves to the given velocity and direction: This function is available to Jog motion with custom accel/decel time value.
<b>FAS_MovePause</b>	The motor starts pause in running or the motor starts again In pause status. The function operates normally only when operated by the position command which has the acceleration time and deceleration time with the same value.

\*1 These functions are available from Firmware [ver.6.1.20.18] or higher version.

## FAS\_MoveStop

---

To stop the motor

### Syntax

```
int FAS_MoveStop(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

### Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

### See Also



## FAS\_EmergencyStop

---

To stop the motor without deceleration

### Syntax

```
int FAS_EmergencyStop(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

This function does not include deceleration phase. So, the user must be careful so that the machine cannot be impacted.

### Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

### See Also

## FAS\_MoveOriginSingleAxis

---

To search the origin of system.

For more information, refer to '[User Manual\\_Text 9.3 Origin Return](#)'.

### Syntax

```
int FAS_MoveOriginSingleAxis(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

### Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

### See Also

## FAS\_MoveSingleAxisAbsPos

---

To move the motor to the absolute coordinate

Syntax

```
int FAS_MoveSingleAxisAbsPos(
    BYTE nPortNo,
    BYTE iSlaveNo,
    long lAbsPos,
    DWORD lVelocity,
);
```

Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*lAbsPos*

Absolute coordinate of position to move

*lVelocity*

Velocity when the motor moves

Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

Remarks

Example

```
#include "FAS_ EziMOTIONPlusR.h"

void funcMove()
{
    BYTE nPortNo = 1; // COMM Port Number
    BYTE iSlaveNo = 0; // Slave No (0 ~ 15)
    DWORD dwAxisStatus, dwInput;
    EZISERVO_AXISSTATUS stAxisStatus;
    long lAbsPos, lIncPos, lVelocity;
    int nRtn;

    // Try to connect
```

```

if (FAS_Connect(nPortNo, 115200) == FALSE)
{
    // Connection failed.
    // The port is not connected or the baudrate may be wrong.
    return;
}

// Check error and Servo ON status.
nRtn = FAS_GetAxisStatus(nPortNo, iSlaveNo, &dwAxisStatus);
_ASSERT(nRtn == FMM_OK);
stAxisStatus.dwValue = dwAxisStatus;

//if (dwAxisStatus & 0x00000001)
if (stAxisStatus.FFLAG_ERRORALL)
    FAS_ServoAlarmReset(nPortNo, iSlaveNo);
//if ((dwAxisStatus & 0x00100000) == 0x00)
if (stAxisStatus.FFLAG_SERVOON == 0)
    FAS_ServoEnable(nPortNo, iSlaveNo, TRUE);

// Check input status.
nRtn = FAS_GetIOInput(nPortNo, iSlaveNo, &dwInput);
_ASSERT(nRtn == FMM_OK);

if (dwInput & (SERVO_IN_LOGIC_STOP | SERVO_IN_LOGIC_PAUSE | SERVO_IN_LOGIC_EST
OP))
    FAS_SetIOInput(nPortNo, iSlaveNo, 0, SERVO_IN_LOGIC_STOP | SERVO_IN_LOGI
C_PAUSE | SERVO_IN_LOGIC_ESTOP);

// Increase the motor to 15000 pulse.
lIncPos = 15000;
lVelocity = 30000;
nRtn = FAS_MoveSingleAxisIncPos(nPortNo, iSlaveNo, lIncPos, lVelocity);
_ASSERT(nRtn == FMM_OK);

// Stand by until motion command is completely finished.
do
{
    Sleep(1);

    nRtn = FAS_GetAxisStatus(nPortNo, iSlaveNo, &dwAxisStatus);
    _ASSERT(nRtn == FMM_OK);
    stAxisStatus.dwValue = dwAxisStatus;
}
while (stAxisStatus.FFLAG_MOTIONING);

// Move the motor to '0'.

```

```
lAbsPos = 0;
lVelocity = 20000;
nRtn = FAS_MoveSingleAxisAbsPos(nPortNo, iSlaveNo, lAbsPos, lVelocity);
_ASSERT(nRtn == FMM_OK);

// Stand by until motion command is completely finished
do
{
    Sleep(1);

    nRtn = FAS_GetAxisStatus(nPortNo, iSlaveNo, &dwAxisStatus);
    _ASSERT(nRtn == FMM_OK);
    stAxisStatus.dwValue = dwAxisStatus;
}
while (stAxisStatus.FFLAG_MOTIONING);

// Disconnect.
FAS_Close(nPortNo);
}
```

See Also

## FAS\_MoveSingleAxisIncPos

---

To move the motor to the incremental coordinate value

### Syntax

```
int FAS_MoveSingleAxisIncPos(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    long lIncPos,  
    DWORD lVelocity  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*lIncPos*

Incremental coordinate of position to move

*lVelocity*

Velocity when the motor moves

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

### Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

### See Also

## FAS\_MoveToLimit

---

To give the motor a command to search the limit sensor

### Syntax

```
int FAS_MoveToLimit(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    DWORD lVelocity,  
    int iLimitDir,  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*lVelocity*

Velocity when the motor moves

*iLimitDir*

Limit direction which the motor moves

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

### Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

### See Also

## FAS\_MoveVelocity

---

To move the motor to the relevant direction and velocity.

This function is also available for Jog motion.

### Syntax

```
int FAS_MoveVelocity(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    DWORD lVelocity,  
    int iVelDir  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*lVelocity*

Velocity when the motor moves

*iVelDir*

Direction which the motor moves ( 0: -Jog, 1: +Jog)

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

### Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

### See Also



## FAS\_PositionAbsOverride

To change the absolute position value set while the motor moves to the absolute position

Syntax

```
int FAS_PositionAbsOverride(
    BYTE nPortNo,
    BYTE iSlaveNo,
    long IOverridePos
);
```

Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*IOverridePos*

Absolute coordinate position value to be changed

Return Value

FMM\_OK : Command has been normally performed.


FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.


FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

Remarks


- 1) If the target position is set to the farther coordinate than the original target position while the motor moves to the accelerated or uniform velocity, the motor moves to the velocity pattern until then and stops the target position.



- 2) If the target position is changed while the motor is decelerated, it is again accelerated up to the uniform velocity and then stops to the target position.



- 3) If the changed target position is set to the closer coordinate than the original target position, the motor move to the changed target position.



#### Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

#### See Also

FAS\_PositionIncOverride

## FAS\_PositionIncOverride

---

To change the incremental position value set while the motor moves to the incremental position

### Syntax

```
int FAS_PositionIncOverride(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    long IOverridePos  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*IOverridePos*

Incremental coordinate position value to be changed

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

- 1) Refer to 'FAS\_PositionAbsOverride' library.
- 2) Can not use with FAS\_PositionIncOverride library at the same time.  
Can not use with FAS\_VelocityOverride library at the same time.

### Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

### See Also

FAS\_PositionAbsOverride

## FAS\_VelocityOverride

To change the velocity set while the motor moves

Syntax

```
int FAS_VelocityOverride(
    BYTE nPortNo,
    BYTE iSlaveNo,
    DWORD lVelocity
);
```

Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*lVelocity*

Velocity to be changed in [pps]

Return Value


FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

Remarks



- 1) In case of ((change speed) < (speed before change)), the motor reaches the change speed through acceleration/deceleration using a new velocity pattern.
- 5) In case of ((change speed) ≥ (speed before change)), the motor reaches the change speed through acceleration/deceleration without any new velocity pattern.
- 4) The motor reaches the 'speed before change' without a change of the velocity pattern and then it reaches the 'change speed' by a new velocity pattern.
- 2), 3) After acceleration/deceleration is finished, the motor reaches the change speed corresponding to the velocity pattern of the 'change speed'.

### Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

### See Also

## FAS\_AllMoveStop

---

To stop the motor that connected in same port.

### Syntax

```
int FAS_AllMoveStop(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product. (must be '99')

### Return Value

No response

### Remarks

### Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

### See Also

## FAS\_AllEmergencyStop

---

To stop the motor that connected in same port without deceleration

### Syntax

```
int FAS_AllEmergencyStop(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product. (must be '99')

### Return Value

No response

### Remarks

This function does not include deceleration phase. So, the user must be careful so that the machine cannot be impacted.

### Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

### See Also

## FAS\_AllMoveOriginSingleAxis

---

To search the origin of all motor that is connected in same port.

For more information, refer to '[User Manual\\_Text 9.3 Origin Return](#)'.

### Syntax

```
int FAS_AllMoveOriginSingleAxis(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product. (must be '99')

### Return Value

No response

### Remarks

### Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

### See Also



## FAS\_MoveLinearAbsPos2

---

Improved version of FAS\_MoveLinearAbsPos.

Acceleration and Deceleration were improved.

### Syntax

```
int FAS_MoveLinearAbsPos2(  
    BYTE nNoOfBds,  
    int* iBdID,  
    long* lplAbsPos,  
    DWORD lFeedrate,  
    DWORD wAcceltime  
);
```

### Parameters

*nNoOfBds*

Number of drives to execute linear motion

*iBdID*

ID array of Drives

*lplAbsPos*

Movement position's arrangement of Drives

*lFeedrate*

Linear velocity value during movement

*wAcceltime*

Time value of acceleration / deceleration section during movement

### Return Value

FMM\_OK : The command ran successfully.

FMM\_NOT\_OPEN : The drive is not connected yet.

FMM\_INVALID\_SLAVE\_NUM : The drive of corresponding iBdID does not exist.

### Remarks

## FAS\_MoveLinearIncPos2

---

Improved version of FAS\_MoveLinearIncPos.

Acceleration and Deceleration were improved.

### Syntax

```
int FAS_MoveLinearIncPos2(  
    BYTE nNoOfBds,  
    int* iBdID,  
    long* lplIncPos,  
    DWORD lFeedreat,  
    DWORD wAcceltime  
);
```

### Parameters

*nNoOfBds*

Number of drives to execute linear motion

*iBdID*

ID array of Drives

*lplAbsPos*

Movement position's arrangement of Drives

*lFeedrate*

Linear velocity value during movement

*wAcceltime*

Time value of acceleration / deceleration section during movement

### Return Value

FMM\_OK : The command ran successfully.

FMM\_NOT\_OPEN : The drive it not connected yet.

FMM\_INVALID\_SLAVE\_NUM : The drive of corresponding iBdID does not exist.

### Remarks

## FAS\_AllMoveSingleAxisAbsPos

---

To move the motor that connected in same port to the absolute coordinate

### Syntax

```
int FAS_AllMoveSingleAxisAbsPos(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    long lAbsPos,  
    DWORD lVelocity,  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product. (must be '99')

*lAbsPos*

Absolute coordinate of position to move

*lVelocity*

Velocity when the motor moves

### Return Value

No response

### Remarks

### Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

### See Also

## FAS\_AllMoveSingleAxisIncPos

---

To move the motor that connected in same port to the incremental coordinate value

### Syntax

```
int FAS_AllMoveSingleAxisIncPos(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    long lIncPos,  
    DWORD lVelocity  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product. (must be '99')

*lIncPos*

Incremental coordinate of position to move

*lVelocity*

Velocity when the motor moves

### Return Value

No response

### Remarks

### Example

Refer to 'FAS\_MoveSingleAxisAbsPos' library.

### See Also

## FAS\_MoveLinearAbsPos

---

To move(Linear Interpolation) more than 2 motors that connected in same port to the absolute coordinate.

### Syntax

```
int FAS_MoveLinearAbsPos(
    BYTE nPortNo,
    BYTE nNoOfSlaves,
    BYTE *iSlaveNo,
    long *lAbsPos,
    DWORD lFeedrate,
    WORD wAccelTime
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*nNoOfSlaves*

Slave numbers for Linear motioning.

*iSlaveNo*

Array of Slave numbers.

*lAbsPos*

Array of position value for each slave.

*lFeedrate*

Speed value for motioning.

*wAccelTime*

Acceleration & deceleration time value.

### Return Value

FMM\_OK : Command has been successfully performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks



## FAS\_MoveLinearIncPos

---

To move(Linear Interpolation) more than 2 motors that connected in same port to the incremental coordinate.

### Syntax

```
int FAS_MoveLinearIncPos(  
    BYTE nPortNo,  
    BYTE nNoOfSlaves,  
    BYTE *iSlaveNo,  
    long *lIncPos,  
    DWORD lFeedrate,  
    WORD wAccelTime  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*nNoOfSlaves*

Slave numbers for Linear motioning.

*iSlaveNo*

Array of Slave numbers.

*lIncPos*

Array of position value for each slave.

*lFeedrate*

Speed value for motioning.

*wAccelTime*

Acceleration & deceleration time value.

### Return Value

FMM\_OK : Command has been successfully performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks





## FAS\_MoveSingleAxisAbsPosEx

---

To move the motor to the absolute coordinate  
(Available to set drive acc/dec time)

Syntax

```
int FAS_MoveSingleAxisAbsPosEx(
    BYTE nPortNo,
    BYTE iSlaveNo,
    long lAbsPos,
    DWORD lVelocity,
    MOTION_OPTION_EX* lpExOption
);
```

Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*lAbsPos*

Absolute coordinate of position to move

*lVelocity*

Velocity when the motor moves

*lpExOption*

Custom option.

Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

Remarks

Refer to MOTION\_OPTION\_EX struct.

Example

```
#include "FAS_EziMOTIONPlusR.h"
```

```
void funcMoveEx()
```

```
{
    BYTE nPortNo = 1; // COMM Port Number
    BYTE iSlaveNo = 0; // Slave No (0 ~ 15)
    DWORD dwAxisStatus, dwInput;
    EZISERVO_AXISSTATUS stAxisStatus;
    long lAbsPos, lIncPos, lVelocity;
```

```

MOTION_OPTION_EX opt = {0};
int nRtn;

// Try to connect
if (FAS_Connect(nPortNo, 115200) == FALSE)
{
    // Connection failed.
    // The port number may be wrong, or incorrect Baudrate.
    return;
}

// Moving motor with different acc/dec time : FAS_MoveSingleAxisIncPosEx
lIncPos = 15000;
lVelocity = 30000;

opt.flagOption.BIT_USE_CUSTOMACCEL = 1;
opt.flagOption.BIT_USE_CUSTOMDECEL = 1;

opt.wCustomAccelTime = 50;
opt.wCustomDecelTime = 200;

nRtn = FAS_MoveSingleAxisIncPosEx(nPortNo, iSlaveNo, lIncPos, lVelocity,
&opt);
_ASSERT(nRtn == FMM_OK);

// Waiting until motion command is done.
do
{
    Sleep(1);

    nRtn = FAS_GetAxisStatus(nPortNo, iSlaveNo, &dwAxisStatus);
    _ASSERT(nRtn == FMM_OK);
    stAxisStatus.dwValue = dwAxisStatus;
}
while (stAxisStatus.FFLAG_MOTIONING);

// Moving motor to position 0.
lAbsPos = 0;
lVelocity = 20000;
nRtn = FAS_MoveSingleAxisAbsPos(nPortNo, iSlaveNo, lAbsPos, lVelocity);
_ASSERT(nRtn == FMM_OK);

// Waiting until motion command is done.
do
{
    Sleep(1);

```

```
        nRtn = FAS_GetAxisStatus(nPortNo, iSlaveNo, &dwAxisStatus);
        _ASSERT(nRtn == FMM_OK);
        stAxisStatus.dwValue = dwAxisStatus;
    }
    while (stAxisStatus.FFLAG_MOTIONING);

    // Disconnect.
    FAS_Close(nPortNo);
}
```

See Also

## FAS\_MoveSingleAxisIncPosEx

---

To move the motor to the Incremental coordinate  
(Available to set drive acc/dec time)

### Syntax

```
int FAS_MoveSingleAxisIncPosEx(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    long lIncPos,  
    DWORD lVelocity,  
    MOTION_OPTION_EX* lpExOption  
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*lIncPos*

Incremental coordinate of position to move

*lVelocity*

Velocity when the motor moves

*lpExOption*

Custom option.

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

### Example

### See Also

## FAS\_MoveVelocityEx

---

To move the motor to the relevant direction and velocity.

This function is also available for Jog motion.

### Syntax

```
int FAS_MoveVelocityEx(
    BYTE nPortNo,
    BYTE iSlaveNo,
    DWORD lVelocity,
    int iVelDir,
    VELOCITY_OPTION_EX* lpExOption
);
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*lVelocity*

Velocity when the motor moves

*iVelDir*

Direction which the motor moves ( 0: -Jog, 1: +Jog)

*lpExOption*

Custom option.

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

Refer to VELOCITY\_OPTION\_EX struct.

### Example

```
#include "FAS_ EziMOTIONPlusR.h"

void funcMoveVelocityEx()
{
    BYTE nPortNo = 1;    // COMM Port Number
    BYTE iSlaveNo = 0;    // Slave No (0 ~ 15)
    long lVelocity;
    VELOCITY_OPTION_EX opt = {0};
```

```
int nRtn;

// Try to connect
if (FAS_Connect(nPortNo, 115200) == FALSE)
{
    // Connection failed.
    // The port number may be wrong, or incorrect Baudrate.
    return;
}

// Moving motor with different acc/dec time : FAS_MoveSingleAxisIncPosEx
lVelocity = 30000;

opt.flagOption.BIT_USE_CUSTOMACCDEC = 1;
opt.wCustomAccDecTime = 300;

nRtn = FAS_MoveVelocityEx(nPortNo, iSlaveNo, lVelocity, DIR_INC, &opt);
_ASSERT(nRtn == FMM_OK);

Sleep(5000);
FAS_MoveStop(nPortNo, iSlaveNo);
}
```

See Also

## 2 – 10. Position Table Control Function

Function Name	Description
<b>FAS_PosTableReadItem</b>	Read item values of desired position table from RAM area.
<b>FAS_PosTableWriteItem</b>	Stores the item value of a desired position table in RAM area.
<b>FAS_PosTableWriteROM</b>	Store all position table values in ROM area : All 256 PT values are saved.
<b>FAS_PosTableReadROM</b>	Read position table values in ROM area : Read all 256 PT values.
<b>FAS_PosTableRunItem</b>	Starts operation sequentially from the designated position table.
<b>FAS_PosTableReadOneItem</b>	Read desired item value of desired position table from RAM area.
<b>FAS_PosTableWriteOneItem</b>	Store desired item value of desired position table in RAM area.

## FAS\_PosTableReadItem

---

Read desired item values of position table.

Syntax

```
int FAS_PosTableReadItem(
    int iBdID,
    WORD wItemNo,
    LPITEM_NODE lpItem
);
```

Parameters

*iBdID*

ID number of the drive. IBdID set by the FAS\_Connect function.

*wItemNo*

Item number to read.

*lpItem*

Item structure pointer to store Item value.

Return Value

FMM\_OK : The command ran successfully.

FMM\_NOT\_OPEN : The drive is not connected yet.

FMM\_INVALID\_SLAVE\_NUM : The drive of corresponding iBdID does not exist.

FMM\_INVALID\_PARAMETER\_NUM : wItemNo is out of range.

Remarks

Example

```
#include "FAS_EziMOTIONPlusE.h"

void funcPosTable()
{
    BYTE sb1 = 192, sb2 = 168, sb3=0, sb4=2 // IP :192.168.0.2
    int iBdID = 0;          // Drive number
    WORD wItemNo;
    ITEM_NODE nodeItem;
    int nRtn;

    // Try to connect
    if (FAS_Connect(sb1, sb2, sb3, sb4, iBdID) == FALSE)
```



```

{
    // Connection failed.

    return;
}

// Read position table value of item No. 20 and change the position value.
wItemNo = 20;
nRtn = FAS_PosTableReadItem(iBdID, wItemNo, &nodelItem);
_ASSERT(nRtn == FMM_OK);

nodelItem.lPosition = 260000; // Change the position value to 260000.
nodelItem.wBranch = 23;      // Set next command to No. 23.
nodelItem.wContinuous = 1;   // Set the next command to
continue immediately without deceleration.

nRtn = FAS_PosTableWriteItem(iBdID, wItemNo, &nodelItem);
_ASSERT(nRtn == FMM_OK);

// The ROM value is loaded, ignoring the currently modified position table
data.
nRtn = FAS_PosTableReadROM(iBdID);
_ASSERT(nRtn == FMM_OK);

// Save current modified position table data to ROM.
nRtn = FAS_PosTableWriteROM(iBdID);
_ASSERT(nRtn == FMM_OK);

// Disconnect
FAS_Close(iBdID);
}

```

See Also

FAS\_PosTableWriteItem

## FAS\_PosTableWriteItem

---

Modify the desired item in the position table.

Syntax

```
int FAS_PosTableWriteItem(
    int iBdID,
    WORD wItemNo,
    LPITEM_NODE lpItem
);
```

Parameters

*iBdID*

ID number of the drive. IBdID set by the FAS\_Connect function.

*wItemNo*

Item number to change

*lpItem*

Item structure pointer to modify.

Return Value

FMM\_OK : The command ran successfully.

FMM\_NOT\_OPEN : The drive is not connected yet.

FMM\_INVALID\_SLAVE\_NUM : The drive of corresponding iBdID does not exist.

FMC\_POSTABLE\_ERROR : An error occurred while writing the position table.

FMM\_INVALID\_PARAMETER\_NUM : wItemNo is out of range.

Remarks

The area where position table data is stored is RAM and ROM.

This function is to save data in RAM area. When power is off, data is deleted.

Example

See Also

## FAS\_PosTableWriteROM

---

Saves all current Position Table Items to ROM area.

Syntax

```
int FAS_PosTableWriteROM(
    int iBdID
```

```
);
```

#### Parameters

*iBdID*

ID number of the drive. IBdID set by the FAS\_Connect function.

#### Return Value

FMM\_OK : The command ran successfully.

FMM\_NOT\_OPEN : The drive is not connected yet.

FMM\_INVALID\_SLAVE\_NUM : The drive of corresponding iBdID does not exist.

FMC\_POSTABLE\_ERROR : An error occurred while saving the position table.

#### Remarks

The area where position table data is stored is RAM and ROM.

This function saves the data in the ROM area. The data is saved even when the power is turned off.

#### Example

#### See Also

FAS\_PosTableReadROM

## FAS\_PosTableReadROM

---

Read the Position Table Item values currently saved in the ROM area.

#### Syntax

```
int FAS_PosTableReadROM(  
    int iBdID  
);
```

#### Parameters

*iBdID*

ID number of the drive. IBdID set by the FAS\_Connect function.

#### Return Value

FMM\_OK : The command ran successfully.

FMM\_NOT\_OPEN : The drive is not connected yet.

FMM\_INVALID\_SLAVE\_NUM : The drive of corresponding iBdID does not exist.

FMC\_POSTABLE\_ERROR : An error occurred while reading the position table.

Remarks

Example

See Also

FAS\_PosTableWriteROM

## FAS\_PosTableRunItem

---

Starts operation sequentially from the designated position table.

### Syntax

```
int FAS_PosTableRunItem(  
    int iBdID,  
    WORD wItemNo  
);
```

### Parameters

*iBdID*

ID number of the drive. IBdID set by the FAS\_Connect function.

*wItemNo*

Item number to start operation.

### Return Value

FMM\_OK : The command ran successfully.

FMM\_NOT\_OPEN : The drive is not connected yet.

FMM\_INVALID\_SLAVE\_NUM : The drive of corresponding iBdID does not exist.

FMM\_INVALID\_PARAMETER\_NUM : wItemNo is out of range.

### Remarks

### Example

### See Also

FAS\_GetAllStatus

FAS\_MoveStop

FAS\_EmergencyStop

## FAS\_PosTableReadOneItem

---

Read desired item value of position table.

Syntax

```
int FAS_PosTableReadOneItem(  
    int iBdID,  
    WORD wItemNo,  
    WORD wOffset,  
    long* lPosItemVal  
);
```

Parameters

*iBdID*

ID number of the drive. iBdID set by the FAS\_Connect function.

*wItemNo*

Item number to read.

*wOffset*

Offset value of the item to read. (Refer to [「1-2-6. Position Table Item」](#))

Return Value

FMM\_OK : The command ran successfully.

FMM\_NOT\_OPEN : The drive is not connected yet.

FMM\_INVALID\_SLAVE\_NUM : The drive of corresponding iBdID does not exist.

FMM\_INVALID\_PARAMETER\_NUM : wItemNo is out of range.

Remarks

Example

See Also

FAS\_PosTableReadItem

FAS\_PosTableWriteOneItem

## FAS\_PosTableWriteOneItem

---

Modify the desired Item value in the Position Table.

### Syntax

```
int FAS_PosTableWriteOneItem(  
    int iBdID,  
    WORD wItemNo,  
    WORD wOffset,  
    long lPosItemVal  
);
```

### Parameters

*iBdID*

ID number of the drive. IBdID set by the FAS\_Connect function.

*wItemNo*

Item number to change

*wOffset*

Offset value of the item to read. (Refer to [「1-2-6. Position Table Item」](#))

### Return Value

FMM\_OK : The command ran successfully.

FMM\_NOT\_OPEN : The drive is not connected yet.

FMM\_INVALID\_SLAVE\_NUM : The drive of corresponding iBdID does not exist.

FMC\_POSTABLE\_ERROR : An error occurred while writing the position table.

FMM\_INVALID\_PARAMETER\_NUM : wItemNo is out of range.

### Remarks

### Example

### See Also

FAS\_PosTableWriteItem

FAS\_PosTableReadOneItem

## 2 – 11. Other Control Function

Function Name	Description
FAS_TriggerOutput_RunA	To generate an output signal at a specific position.
FAS_TriggerOutput_Status	To check if the trigger output pulse(COMP) is working or not.



## FAS\_TriggerOutput\_RunA

---

To start/stop the digital output signal(Compare Out pin) when reaching the specific Taregt position.

### Syntax

```
int FAS_TriggerOutput_RunA(
  BYTE nPortNo,
  BYTE iSlaveNo,
  BOOL bStartTrigger,
  long lStartPos,
  DWORD dwPeriod,
  DWORD dwPulseTime,
  );
```

### Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*bStartTrigger*

Output start/stop command (1:start, 0:stop)

*long lStartPos*

Output start position [pulse]

*DWORD dwPeriod*

Period of output signal [pulse]

*DWORD dwPulseTime*

Pulse width of output signal [msec]

### Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

### Remarks

### Example

See Also

FAS\_TriggerOutput\_Status

## FAS\_TriggerOutput\_Status

---

To check if the trigger output function is working or not.

Syntax

```
int FAS_TriggerOutput_Status(  
    BYTE nPortNo,  
    BYTE iSlaveNo,  
    BYTE* bTriggerStatus  
);
```

Parameters

*nPortNo*

Port number of relevant product.

*iSlaveNo*

Slave number of relevant product.

*bTriggerStatus*

Current status of signal output.

Return Value

FMM\_OK : Command has been normally performed.

FMM\_NOT\_OPEN : The product has not been connected yet.

FMM\_INVALID\_PORT\_NUM : There is no nPort in the connected ports.

FMM\_INVALID\_SLAVE\_NUM : There is no Slave of iSlaveNo in the relevant port.

Remarks

Example

See Also


FAS\_TriggerOutput\_RunA

### 3 . Protocol for PLC Program

As follows window is open when you click in User Program(GUI) installed folder.

The example below will help you to understand the protocol programming.

(1)Protocol for Servo ON/OFF command



The header and tail information are needed for protocol programming. Additionally Frame Data (Slave ID, Frame type, Data and CRC) is also needed in every protocol with header and tail.

- 1)Select 'Comm Port','Baudrate' and then click 'Connect' button.
  - 2)Header : Click 'Header' and you can see '[0XAA][0xCC]' on 'Send Buffer' window.
  - 3)Slave ID : Insert connected slave number(above example is '0') and click 'SlaveNo'.
  - 4)Frame type : Select 'Frame type'.
- You can check as below table information at '1-2-1. Frame Type and Data Configuration'.

Frame type	DLL Library name	Data		
42 (0x2A)	FAS_ServoEnable	Setting the Servo ON/OFF status. Sending : 1 byte <table><tr><td>1 byte</td></tr><tr><td>0:OFF, 1:ON</td></tr></table>	1 byte	0:OFF, 1:ON
1 byte				
0:OFF, 1:ON				

- Input '42' and the size of receive frame type is 1byte, so click '1 byte'.
- 5)Data : To make Servo ON status, the designated command is '1'. Input '1' and click'1 byte'.
  - 6)CRC : If click 'CRC', calculate checksum value automatically and expressed as 2 byte size.
  - 7)Tail : Click 'Tail' and you can see '[0XAA][0xEE]' on 'Send Buffer' window.
  - 8)Finally click 'Send' button to send command characters to Ezi-MOTIONLINK Plus-R. You can check the motor torque and LED flash for Servo ON status.
  - 9) A command is sent to Ezi-MOTIONLINK Plus-R normally and information which is received normally from Ezi-MOTIONLINK Plus-R is expressed at 'Buffer Received' window.

## (2) Protocol for motor motion command

**Protocol Test**

**Connection**  
 Comm Port: 77  
 Baudrate: 115200  
 Disconnect

**Send Buffer**  
 [0xAA] [0xCC] [0x00] [0x35] [0x10] [0x27] [0x00] [0x00]  
 [0x88] [0x13] [0x00] [0x00] [0x3D] [0x97] [0xAA] [0xEE]

1. Header: 0    2. SlaveNo:   

3. Data: 5000    1 byte    2 bytes    4 bytes

4. CRC    5. Tail

CLEAR    SEND >>

**Buffer Received**  
 [Header] Slv Cmd Stat  
 0xAA 0xCC 0x00 0x35 0x00 0x66 0x90 0xAA 0xEE

**Values**  
 BYTE :    Static    CHAR :    Static  
 WORD :    Static    SHORT :    Static  
 DWORD :    Static    LONG :    Static

- 1) Header
- 2) Slave No.
- 3) Frame type : Input '53' for 'Incremental Move'command.
- 4) Data(Position value) : Input'10000'and click '4byte'.
- 5) Data(Running speed) : Input'5000'and click '4 byte'.
- 6) CRC
- 7) Tail
- 8) Send : If parameter is 'default', the motor rotates 360 degree. Command '53' is an incremental move command, so if tou click 'Send" again, the motor rotates same amount of distance.

## (3)PLC Programming

Between the actual protocol program and the above example have difference as below. In GUI program for a test, a function below is carried out automatically.

- 1) For clear separation between Header and Tail, use 'Byte stuffing' technique.  
 Refer to 「1-1-2. RS-485 Communication Protocol(Ver6)」.
- 2) Use CRC function to check communication error.
- 3) Refer to 「1-1-3. CRC Calculation Example」.

**FASTECH Co., Ltd.**

Rm#1202, 401-dong, Bucheon Techno-Park,  
655, Pyeongcheon-ro, Bucheon-si Gyeonggi-do,  
Republic of Korea (Zip:14502)  
TEL : +82-32-234-6300 FAX : +82-32-234-6302  
E-mail : [fastech@fastech.co.kr](mailto:fastech@fastech.co.kr)  
Homepage : [www.fastech.co.kr](http://www.fastech.co.kr)

- It is prohibited to unauthorized or reproduced in whole or in part described in the User's Guide
- If you need a user manual to the loss or damage, etc., please contact us or your nearest distributor.
- User manual are subject to change without notice to improve the product or quantitative changes in specifications and user's manual.
- Ezi-MOTIONLINK Plus-R is registered trademark of FASTECH Co., Ltd in the national registration

© Copyright 2015 FASTECH Co.,Ltd. Jan 25, 2021 Rev.04